# SANYO TROUBLESHOOTING GUIDE 2010 MODELS DP26640 & DP32640

This guide is divided into 4 sections/pages depending on type of defect:

- page 1) No Green LED Power Light (LED never turns "ON")
- page 2) Green LED Light is "ON", but Backlights are not "ON", or only turn "ON & then OFF".
- page 3) Green LED Light is "ON", and Backlights are "ON", but there is no video/OSD.
- page 4) Green LED Light turns "ON", but turns "OFF" within 10 seconds, or LED cycles ON & OFF.

Please select the section/page that matches your defect and follow the flow chart.

These models & chassis versions are in this guide:

DP26640-00

DP26640-01

DP26640-02

DP26640-04

DP32640-00


DP32640-01

DP32640-03

# PLEASE KEEP THIS GUIDE. IT WILL NOT BE PROVIDED FOR EVERY REPAIR.

techsupport@sanyotv.com

# Repair Flow Chart: Trouble Condition Green Power LED does NOT turn on. The TV is dead.



#### (TABLE \*1.0) Main Bd.: 5V STBY Test Points


(TABLE TIO	TABLE #1.0/ Main bd.: 5V_STBT Test Foints										
26" Models		32" Models		5V_STBY on Main Bd.	Confirmation Voltage						
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 4"	5 V						
DP26640-01	N8MF	DP32640-01	N8LF								
DP26640-02	N8MG	DP32640-03	N8LH								
DP26640-04	HM8N										

### (TABLE \*2.0) Power Bd.: 5V\_STBY Test Points

(1) (DEL - E.O	(1) IBEE - Eley 1 evel Ball ev_e1B1 1 eet 1 evile									
26" Models		32" Models		5V_STBY on Power Bd.	Confirmation Voltage					
DP26640-00	N8ME	DP32640-00	N8LE	CN2 "pin 4"	5 V					
DP26640-04	N8MH	DP32640-03	N8LH							
DP26640-01	N8MF	DP32640-01	N8LF	K6B "pin 4"	5 V					
DP26640-02	N8MG									

Green Power LED is on, but LCD backlights are not on.

Backlights do not turn on, or only turn on and back off.



#### (TABLE \*1.0) 12V Test Points

26" Models		32" Models		12V on Main Bd.	Confirmation Voltage
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 8"	12 V
DP26640-01	N8MF	DP32640-01	N8LF		
DP26640-02	N8MG	DP32640-03	N8LH		
DP26640-04	N8MH				

#### (TABLE \*1.1) 24V Test Points

26" Mo	26" Models 32" Models		dels	24V on Power Bd.	Confirmation Voltage
DP26640-00	N8ME	DP32640-00	N8LE	n/a	n/a
DP26640-04	N8MH	DP32640-03	N8LH		
DP26640-01	N8MF	DP32640-01	N8LF	Power Bd. K603 "pin 1"	24 V
DP26640-02	N8MG				


#### (TABLE \*2.0) Main Bd.: "Power ON/OFF SW" Test Points

26" Models		32" Models		Power ON/OFF SW on Main Bd.	Confirmation Voltage
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 1"	5 V
DP26640-01	N8MF	DP32640-01	N8LF		
DP26640-02	N8MG	DP32640-03	N8LH		
DP26640-04	N8MH				

#### (TABLE \*3.0) Main Bd.: "BL\_ON" Test Points

(IIIDEE 3.	(TIBLE 5.0) Main Bui. BE_511 Test I ones									
26" Models		32" Models		BL_ON Command	Confirmation Voltage					
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 13"	3.3 V					
DP26640-01	N8MF	DP32640-01	N8LF							
DP26640-02	N8MG	DP32640-03	N8LH							
DP26640-04	N8MH									

Green Power LED and LCD backlights are on, but no video or OSD.



(TABLE \*1.0) Main Bd.: 12V Test Points

26" Models		32" Models		12V on Main Bd.	Confirmation Voltage
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 8"	12 V
DP26640-01	N8MF	DP32640-01	N8LF		
DP26640-02	N8MG	DP32640-03	N8LH		
DP26640-04	N8MH				

(TABLE \*2.0) Main Bd.: "T-CON Power supply" Test Points


26" Models		32" Models		12V on Main Bd.	Confirmation Voltage
DP26640-00	N8ME	DP32640-00	N8LE	Main K5LV "pin 23"	12 V
DP26640-01	N8MF	DP32640-01	N8LF		
DP26640-02	N8MG	DP32640-03	N8LH		
DP26640-04	N8MH				

#### (TABLE \*3.0) Main Bd.: "LVDS Clock" Test Points

26" Models 32" Models		odels	LVDS Clock on Main Bd.	Confirmation Voltage	
DP26640-00	N8ME	DP32640-00	N8LE	K5LV pin #11: Clock -	Waveform will be
DP26640-01	N8MF	DP32640-01	N8LF	K5LV pin #12: Clock +	200 - 450 mV
DP26640-02	N8MG	DP32640-03	N8LH		74.25 MHz
DP26640-04	N8MH				range = 10-20ns/div

note: The bandwidth of the oscilloscope and probe must be at least 100 MHZ or higher to check if the clock pluse exists

## Power LED turns OFF within 10 sec of Power ON, or LED cycles ON & OFF.



#### (TABLE \*1.0) Main Bd.: "Power ON/OFF SW" Test Points

(IIIDEE II	(TIBBLE 110) Ham Buil 1 Uver Of VOIT DV Test 1 Units									
26" Models		32" Models		5V on Main Bd.	Confirmation Voltage					
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 1"	5 V					
DP26640-01	N8MF	DP32640-01	N8LF							
DP26640-02	N8MG	DP32640-03	N8LH							
DP26640-04	N8MH									

#### (TABLE \*2.0) 12V Test Points

(IADLE 2	(TABLE 2.0) 12 v Test I onts										
26" Models		32" Models		12V on Main Bd.	Confirmation Voltage						
DP26640-00	N8ME	DP32640-00	N8LE	Main K8C "pin 8"	12 V						
DP26640-01	N8MF	DP32640-01	N8LF								
DP26640-02	N8MG	DP32640-03	N8LH								
DP26640-04	N8MH										

#### (TABLE \*2.1) 24V Test Points

(TABLE 2.	(IABLE 2.1) 24 V Test Folias									
26" Models		32" Models		24V on Power Bd.	Confirmation Voltage					
DP26640-00	N8ME	DP32640-00	N8LE	n/a	n/a					
DP26640-04	N8MH	DP32640-03	N8LH							
DP26640-01	N8MF	DP32640-01	N8LF	Power Bd. K603 "pin 1"	24 V					
DP26640-02	N8MG									



FILE NO.

## **SERVICE MANUAL**

# **Remote Control Digital Color Television**

# **DP26640** (U.S.A.) (CANADA)

**ORIGINAL VERSION** 



Chassis No. P26640-01

NOTE: Match the Chassis No. on the unit's back cover with the Chassis No. in the Service Manual.

> If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.

# Servicing should be performed by only trained and qualified service personnel.

# SAFETY INSTRUCTIONS

Contents

SALLIT INSTRUCTIONS
SERVICE ADJUSTMENTS
ON-SCREEN SERVICE MENU
POWER FAILURE CIRCUIT
MECHANICAL DISASSEMBLY
CHASSIS ELECTRICAL PARTS LIST
COMPONENT AND TESTPOINT LOCATIONS 18
BLOCK DIAGRAM POWER LINES2
BLOCK DIAGRAM SIGNAL LINES
IC BLOCK DIAGRAMS
TROUBLESHOOTING FLOW CHARTS 29
CONTROL PORT FUNCTIONS32
ZORAN 772 PERIPHERICALS34
SCHEMATIC NOTES3!
IC, DIODE, AND TRANSISTOR PIN LAYOUTS36
PC BOARD CONNECTIONS AND LOCATIONS 37
CAPACITOR AND RESISTOR CODE CHART 38
SCHEMATIC DIAGRAMS39

# **Specifications**

POWER RATING 120VAC
95W (AVG.)
ANTENNA INPUT IMPEDANCE
UHF/VHF/CATV
DIGITAL
RECEIVING CHANNEL 2 - 13 (VHF),
14 - 69 (UHF),
01, 14-94, 95-135 (CATV)
1-135 (DIGITAL)
REMOTE READY 32 KEY REMOTE CONTROL
SOUND OUTPUT 5.0 W/CH
INTERMEDIATE FREQUENCY
PICTURE IF CARRIER 45.75MHz
SOUND IF CARRIER 41.25MHz
COLOR SUB CARRIER 42.17MHz
CABINET DIMENSIONS
WIDTH
HEIGHT 484mm
DEPTH INCLUDING BASE 241mm

## SAFETY INSTRUCTIONS

#### **SAFETY PRECAUTIONS**

WARNING: The chassis of this receiver has a floating ground with the potential of one half the AC line voltage in respect to earth ground. Service should not be attempted by anyone not familiar with the precautions necessary when working on this type of equipment.

The following precautions must be observed:

- An isolation transformer must be connected in the power line between the receiver and the AC line before any service is performed on the receiver.
- Comply with all caution and safety-related notes provided inside the cabinet, on the chassis, and on the back.
- When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as control knobs, adjustment covers, shields and barriers.
- 4. Before replacing the back cover of the set, thoroughly inspect the inside of the cabinet to see that no stray parts or tools have been left inside.

Before returning any television to the customer, the service technician must perform the following safety checks to be sure that the unit is completely safe to operate without danger of electrical shock.

#### ANTENNA COLD CHECK

Remove AC plug from the 120 VAC outlet and place a jumper across the two blades. Connect one lead of an ohmmeter to the jumpered AC plug, and touch the other lead to each exposed antenna terminal (UHF and VHF antenna terminals). The resistance must measure between 1M ohm and 5.2M ohm. Any resistance value below or above this range indicates an abnormality which requires corrective action.


### LEAKAGE CURRENT CHECK

Plug the AC line cord directly into a 120 VAC outlet. (Do not use an isolation transformer for this check.) Use an AC voltmeter, that has 5000 ohms per volt or more sensitivity. Connect a 1500 ohm 10 watt resistor, paralleled by a 0.15  $\mu\text{F}$  150 VAC capacitor, between a known good earth ground (water pipe, conduit, etc.) and all exposed metal parts of the cabinet (antennas, handle bracket, metal cabinet, screw heads, metal overlays, control shafts, etc.). Measure the AC voltage across the 1500 ohm resistor. The AC voltage should not exceed 750 mV. A reading exceeding 750 mV indicates that a dangerous potential exists. The fault must be located and corrected. Repeat the above test with the receiver power plug reversed.

NEVER RETURN A RECEIVER TO THE CUSTOMER WITHOUT TAKING THE NECESSARY CORRECTIVE ACTION.

#### PRODUCT SAFETY NOTICE

When replacing components in a receiver, always keep in mind the necessary product safety precautions. Pay special attention to the replacement of components marked with a **\( \Lambda \)** in the parts list and in the schematic diagrams. To ensure safe product operation, it is necessary to replace those components with the exact same PARTS.



#### SERVICING ELECTROSTATICALLY SENSITIVE DEVICES

Semiconductors (solid-state devices) that can be damaged by static electricity are referred to as Electrostatically Sensitive (ES) devices. Examples of typical ES devices are: Integrated Circuits (IC), Field-Effect Transistors (FET), and "chip" components. The following techniques should be observed strictly, to reduce the occurrence of semiconductor damage due to electrostatic discharge.

 Immediately prior to handling any semiconductor component or an assembly containing a semiconductor device or devices, discharge the electrostatic buildup on your body by touching a known earth ground. You may also obtain and wear a commercially available discharging wrist strap device.

**CAUTION**: Be sure to remove the wrist strap before applying power to any unit being serviced.

- 2. After removing an ES equipped assembly, place it on a conductive surface, such as, aluminum foil, to prevent buildup or exposure to static electricity.
- Use only grounded-tip soldering irons to solder or unsolder ES devices.
- Use only anti-static solder removal devices. Some suction-type devices can generate static electricity adequate to damage ES devices.
- 5. A replacement ES device will come packaged in protective material (conductive foam, aluminum foil, or some comparable conductive material). Do Not remove an ES device from its protective packaging unless you are prepared to install it immediately.
- Precisely prior to removing an ES device from its protective packaging, touch the protective packaging to the chassis or assembly in which the device will be installed.

**CAUTION:** Be sure that no power is applied to the chassis or circuit assembly.

7. Incidental body movements, such as, lifting a foot from a carpeted floor or the rubbing of fabric together can generate static electricity sufficient to damage ES devices. Therefore, minimize all body movements while handling exposed (unpackaged) ES devices.

# **SERVICE ADJUSTMENTS**

#### **GENERAL**

This set has an On-screen Service Menu system included in the CPU that allows remote operation for most of the service adjustments.

### **ON-SCREEN SERVICE MENU SYSTEM**

#### 1. Enter the Service Menu:

- Turn off the receiver and disconnect the AC power supply.
- While pressing the Volume "-" button on the television, reconnect the AC power supply. The Service Menu will now appear. The remote can now be used to make adjustments. See Figure 1 below.



Figure 1. Service Menu Display


#### 2. Service Adjustments:


- Press the Cursor ▲ or ▼ key to select the desired service menu item you want to adjust. See page 4 for the On-screen Service Menu.
- Use the Cursor < or > key to adjust the data. The < or > key will increase or decrease the data sequentially.

#### 3. Exit from the Service Menu:

• Press the MENU key to turn off the Service Menu display.

Menu:





# **ON-SCREEN SERVICE MENU**

#### Table 1. ON-SCREEN SERVICE MENU

When IC803 (EEPROM) is replaced, check the bus data to confirm they are the same as below. See page 3 for On-Screen Service Menu access and adjustments.

No.	Title	Initial Data	Note		
1A0	MUTE	A0h	Audio mute at Power ON		
086	VOL	30h	Volume setup inspection		
087	OP1	00h	Option 1 Data (TV Guide/HOTEL mode)		
088	OP2	22h	Option 2 Data (Display Panel)		
101	1R00	00h	ROM Correction Data		
102	1R01	00h	ROM Correction Data		
$\downarrow$	↓	<b>1</b>	↓		
197	2R47	00h	ROM Correction Data		
198	2R48	00h	ROM Correction Data		

- All data except in gray box area is fixed. Do not change for correct operating.
- Data in gray box is initial and can be set according to adjusment information.

#### **PROGRAM CODES**

The microprocessor used in this model is a multi-purpose type and is used in several different models. To ensure proper operation and the correct features for your particular model, the program codes must be correct.

Note 1. Option Data 1 (NO. 087 OP1) should be hexadecimal 00. See 087 above. If this program code is wrong the TV will not operate properly.

Note 2. Option Data 2 (NO. 088 OP2) should be hexadecimal 22. See 088 above. If this program code is wrong the TV will not operate properly.

## **POWER FAILURE CIRCUIT**

SUB-CPU (IC800) is programmed so the set will go to standby mode when there is circuit failure as described below. (Refer to "Block Diagram Power Lines".)

This unit is equipped with a Power Failure Detector function included in the SUB-CPU which checks for an abnormal condition in the chassis power supplies.

If, while the power is on, a failure is caused by any of the following that results in a low voltage supply, the SUB-CPU will turn the unit off in 1.5 seconds to prevent further damage:

- Failure within the power supply circuits.
- A short circuit in the load side from the supply.

**Power Failure:** Detected voltage failure for circuit. (Connected to IC800 pin 48 and pin 23.)

(Normal: High; Failure: Low)


If, while the power is off, the power is switched on and any of these failures remains uncorrected, the SUB-CPU will shut off the power within three seconds.

Check the following if the unit is turned off by the power failure detector.

- Disconnect the AC power cord (120V AC line) for a short time.
- 2. Connect a DC Voltmeter to the circuits shown below.
- Press the Power key and check for the proper voltage supplies.
- 4. If any of these voltages is low, the power failure detector should turn the unit off within three seconds.
- 5. Check all circuits shown below.

Note: If power failure is detected 3 times in 15 minutes, the set will enter the standby mode and cannot be switched On.To reset the operating programs of the SUB-CPU it is necessary to disconnect the AC cord for a short time.

#### Main




# **MECHANICAL DISASSEMBLY**

CAUTION: This LCD TV uses several different kinds of screws. Using the correct screw is necessary to prevent damage. Lead wires must be redressed to their previous locations after servicing.

## **BACK LID REMOVAL**

Remove 3 screws to take the Back Lid off. (A:2x6, 2pcs.; C:3x14, 1 pc.)



## STAND REMOVAL

Position TV face down on a padded or cushioned surface to protect the screen and finish.

Remove 4 screws (B: 6X12) to take the stand off.




## **MAIN BOARD REMOVAL**

Remove 5 screws (C:3x14) to take the main board off.

## **POWER UNIT REMOVAL**

Remove 6 screws (C:3x14) to take the power unit off.




#### **ELECTROSTATICALLY SENSITIVE DEVICES**



Many solid-state devices (especially Integrated Circuits) are Electrostatically Sensitive, and, therefore, require special handling techniques as described under "Servicing Electrostatically Sensitive Devices," on page two in this service literature.


## **BACK CABINET REMOVAL**

Remove 14 screws to take the back cabinet off. (C:3x14, 10 pcs.; D:4x8, 4 pcs.)



## **LCD PANEL REMOVAL**

- 1. Remove 8 screws to take the mounting panel off. (A:3x6, 6 pcs.; D:4x8, 2 pcs.)
- 2. Remove 6 screws to take the inverter unit off. (E:2.5x6, 6 pcs.)
- 3. Lift up the LCD panel from from cabinet.




## **SPEAKER REMOVAL**

Take off each speaker from back cabinet.


## [ATTENTION]

Confirm Mounting wall wire is installed when you install the back cabinet.




## **KEY SW BOARD REMOVAL**

Remove 1 screw (C: 3x14) to take the KEY SW board off.



## **RC LED BOARD REMOVAL**

Rremove 1 screw (C: 3x14) to take the RC LED board off.



## [ATTENTION]

The Earth sheet and gasket are provided to prevent interference to other radio and television receivers. The Earth sheet and gasket should be returned to its previous position after servicing.

## CHASSIS ELECTRICAL PARTS LIST

CAUTION: To Protect against electrical shock and for continued product safety, refer to SAFETY PRECAUTIONS and PRODUCT SAFETY NOTICE on Page 2.

#### **PRODUCT SAFETY NOTICE**

PRODUCT SAFETY SHOULD BE CONSIDERED WHEN A REPLACEMENT IS MADE IN ANY AREA OF A RECEIVER. COMPONENTS INDICATED BY A  $\triangle$  IN THIS PARTS LIST AND THE SCHEMATIC DIAGRAM DESIGNATE COMPONENTS IN WHICH SAFETY CAN BE OF SPECIAL SIGNIFICANCE. IT IS PARTICULARLY RECOMMENDED THAT ONLY PARTS DESIGNATED ON THE FOLLOWING PARTS LIST BE USED FOR COMPONENT REPLACEMENT DESIGNATED BY A  $\triangle$ . NO DEVIATIONS FROM RESISTANCE, WATTAGE, AND VOLTAGE RATINGS MAY BE MADE FOR REPLACEMENT ITEMS DESIGNATED BY A  $\triangle$ .


Note: Schematic part location numbers may not always match with the part descriptions. The part descriptions are correct and should be used.

Schematic Location Part No. Description

#### **CAPACITORS**

#### NOTES:

Read description of the Capacitor as follows:




CERAMIC............ Ceramic
MT-PAPER........ Metallized Paper
POLYESTER...... Polyester
MT-POLYEST..... Metallized Polyester
POLYPRO....... Polypropylene
MT-POLYPRO.... Metallized Polypropylene
COMPO FILM.... Composite Film
MT-COMPO..... Metallized Composite
STYRENE..... Styrene
TA-SOLID...... Tantalum Solid
AL-SOLID...... Aluminium Solid
ELECT...... Electrolytic
NP-ELECT...... Non-polarised Electrolytic
OS-SOLID...... Aluminium Solid with Organic
Semiconductive Electrolytic

## **RESISTORS**

#### NOTES

Read description of the Resistor as follows:



Schematic Location	Part No.	De	scription		Schem Locatio		Part No.	De	escription	
	CAPACITOR	<u>s</u>			C162	20	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C016	CK1E105KGMBNG	CERAMIC	1U K	25V	C162	22	CEXLB0J221VEN	ELECT	220U M	6.3V
C017	CEXLB1C222VDN	ELECT	2200U M	16V	C162	23	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C018	CK1A105KLZBNG	CERAMIC	1U K	10V	C162	24	CEXLB1C471VEN	ELECT	470U M	16V
C019	CK1A105KLZBNG	CERAMIC	1U K	10V	C164	10	CEXLB1C101VEN	ELECT	100U M	16V
C020	CEXLB1C102VDN	ELECT	1000U M	16V	C164	11	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C021	CK1A105KLZBNG	CERAMIC	1U K	10V	C164	12	CK1H223KLZBNG	CERAMIC	0.022U K	50V
C022	CK1A105KLZBNG	CERAMIC	1U K	10V	C164	13	CK1A105KLZBNG	CERAMIC	1U K	10V
C023	CK1A105KLZBNG	CERAMIC	1U K	10V	C164	15	CK1H472KLZBNG	CERAMIC	4700P K	50V
C024	CK1E474KLZBNG	CERAMIC	0.47U K	25V	C164	16	CK1A105KLZBNG	CERAMIC	1U K	10V
C025	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C164	17	CEXLB0J102VEN	ELECT	1000U M	6.3V
C027	CK1E224KLZBNG	CERAMIC	0.22U K	25V	C167	70	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C028	CK1A105KLZBNG	CERAMIC	1U K	10V	C167	71	CK1E105KGMBNG	CERAMIC	1U K	25V
C029	CK1E474KLZBNG	CERAMIC	0.47U K	25V	C167	72	CEXLB1V470VDN	ELECT	47U M	35V
C030	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C167	73	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C031	CEXLB1H4R7VDN	ELECT	4.7U M	50V	C167	74	CEXLB1C471VDN	ELECT	470U M	16V
C032	CK1E105KGMBNG	CERAMIC	1U K	25V	C169	91	CK1H103KLZBNG	CERAMIC	0.01U K	50V
C033	CK1A105KLZBNG	CERAMIC	1U K	10V	C183	35	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C035	CK1A105KLZBNG	CERAMIC	1U K	10V	C183	36	CK1H103KLZBNG	CERAMIC	0.01U K	50V
C038	CK1A105KLZBNG	CERAMIC	1U K	10V	C183	37	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C039	CK1A105KLZBNG	CERAMIC	1U K	10V	C240	)3	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C040	CK1E474KLZBNG	CERAMIC	0.47U K	25V	C240	)4	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C041	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C240	)5	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C043	CK1E224KLZBNG	CERAMIC	0.22U K	25V	C240	)6	CEXLB0J221VDN	ELECT	220U M	6.3V
C044	CK1E474KLZBNG	CERAMIC	0.47U K	25V	C240	)8	CK1A105KLZBNG	CERAMIC	1U K	10V
C045	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C241	10	CK1A105KLZBNG	CERAMIC	1U K	10V
C047	CK1E105KGMBNG	CERAMIC	1U K	25V	C244	10	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C048	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C244	15	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C049	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C550	00	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C050	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C550	)1	CK1A105KLZBNG	CERAMIC	1U K	10V
C051	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C550	)2	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C800	CK1A105KLZBNG	CERAMIC	1U K	10V	C550	)3	CK1A105KLZBNG	CERAMIC	1U K	10V
C801	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C550	)4	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C802	CC1H470JLZCNG	CERAMIC	47P J	50V	C550	)5	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C804	CEXLB0J221VDN	ELECT	220U M	6.3V	C550	)6	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C805	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C550	)7	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C806	CC1H270JLZCNG	CERAMIC	27P J	50V	C550	8(	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C807	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C550	)9	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C813	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C551	10	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C815	CC1H270JLZCNG	CERAMIC	27P J	50V	C551	11	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C816	CC1H270JLZCNG	CERAMIC	27P J	50V	C551	12	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C817	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C551	13	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C818	CC1H220JLZCNG	CERAMIC	22P J	50V	C551	15	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C819	CC1H220JLZCNG	CERAMIC	22P J	50V	C551	16	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1000	CEXLB1V470VDN	ELECT	47U M	35V	C551	17	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C1002	CK1A105KLZBNG	CERAMIC	1U K	10V	C551	18	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1004	CK1A105KLZBNG	CERAMIC	1U K	10V	C551	19	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1006	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	21	CK1A105KLZBNG	CERAMIC	1U K	10V
C1008	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	22	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1010	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	23	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C1012	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	24	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1014	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	25	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V
C1016	CK1A105KLZBNG	CERAMIC	1U K	10V	C552	26	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1611	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C552	27	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C1612	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C552	28	CC1H471JLZCNG	CERAMIC	470P J	50V
C1616	CK1H473KLZBNG	CERAMIC	0.047U K	50V	C552	29	CC1H471JLZCNG	CERAMIC	470P J	50V

Schematic Location	Part No.	Des	scription		Schematic Location	Part No.	De	escription	
C5530	CK1A105KLZBNG	CERAMIC	1U K	10V	C5596	CK1H103KLZBNG	CERAMIC	0.01U K	50V
C5531	CK1A105KLZBNG	CERAMIC	1U K	10V	C5597	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5532	CC1H471JLZCNG	CERAMIC	470P J	50V	C5598	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5533	CC1H471JLZCNG	CERAMIC	470P J	50V	C5599	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5534	CK0J106KGMBNG	CERAMIC	10U K	6.3V	C5600	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5535	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5601	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5536	CK1A105KLZBNG	CERAMIC	1U K	10V	C5602	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5537	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5603	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5538	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5604	CK1H103KLZBNG	CERAMIC	0.01U K	50V
C5539	CC1H471JLZCNG	CERAMIC	470P J	50V	C5607	CC1H150JLZCNG	CERAMIC	15P J	50V
C5540	CK1H103KLZBNG	CERAMIC	0.01U K	50V	C5608	CC1H220JLZCNG	CERAMIC	22P J	50V
C5541	CK1H103KLZBNG	CERAMIC	0.01U K	50V	C5611	CK1H103KLZBNG	CERAMIC	0.01U K	50V
C5542	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5612	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5543	CC1H120JLZCNG	CERAMIC	12P J	50V	C5613	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5544	CC1H3R0CLZCNG	CERAMIC	3P C	50V	C5614	CK1E224KLZBNG	CERAMIC	0.22U K	25V
C5545	CC1H390JLZCNG	CERAMIC	39P J	50V	C5616	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5546	CC1H12OJLZCNG	CERAMIC	12P J	50V	C5618	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5547	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5619	CK1A105KLZBNG	CERAMIC	1U K	10V
C5548	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5620	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5549	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5621	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C5550	CK1H104KLZBNG	CERAMIC	0.1U K	50V	C5622	CK1A105KLZBNG	CERAMIC	1U K	10V
C5551	CK1A105KLZBNG	CERAMIC	1U K	10V	C5623	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5552	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5624	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5553	CKOJ106KGMBNG	CERAMIC	10U K	6.3V	C5625	CK0J106KGMBNG	CERAMIC	10U K	6.3V
C5554	CK1A105KLZBNG	CERAMIC	1U K	10V	C5627	CC1H680JLZCNG	CERAMIC	68P J	50V
C5555	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5628	CC1H680JLZCNG	CERAMIC	68P J	50V
C5556	CK0J106KGMBNG	CERAMIC	10U K	6.3V	C5629	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5558	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5630 C5631	CK1A105KLZBNG CK1H104ZLZFNG	CERAMIC	1U K 0.1U Z	10V 50V
C5559	CK1H104ZLZFNG	CERAMIC CERAMIC	0.1U Z	50V 6.3V	C5632	CK1H104ZLZFNG CK1H104ZLZFNG	CERAMIC	0.10 Z 0.1U Z	50V 50V
C5560 C5561	CK0J106KGMBNG CK1H104ZLZFNG	CERAMIC	10U K 0.1U Z	50V	C5647	CC1H221JLZCNG	CERAMIC CERAMIC	220P J	50V 50V
C5563	CK1H104ZLZFNG	CERAMIC	0.10 Z 0.1U Z	50V	C5648	CC1H221JLZCNG	CERAMIC	220P J	50V 50V
C5564	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V	C5649	CC1H221JLZCNG	CERAMIC	220P J	50V
C5565	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5653	CC1H221JLZCNG	CERAMIC	220P J	50V
C5566	CK1H104ZLZFNG	CERAMIC	0.10 Z	50V	C5654	CC1H221JLZCNG	CERAMIC	220P J	50V
C5568	CK1H104ZLZFNG	CERAMIC	0.10 Z	50V	C5655	CC1H221JLZCNG	CERAMIC	220P J	50V
C5569	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V	C5700	CK1A105KLZBNG	CERAMIC	1U K	10V
C5570	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5701	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5572	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V	C5702	CK1A105KLZBNG	CERAMIC	1U K	10V
C5574	CKOJ475KLZBNG	CERAMIC	4.7U K	6.3V	C5703	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5575	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5704	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5576	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V	C5705	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5577	CK1A105KLZBNG	CERAMIC	1U K	10V	C5707	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5578	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V	C5708	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5580	CK1E474KLZBNG	CERAMIC	0.47U K	25V	C5709	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5581	CK1E224KLZBNG	CERAMIC	0.22U K	25V	C5711	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5583	CK1E224KLZBNG	CERAMIC	0.22U K	25V	C5712	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5585	CC1H221JLZCNG	CERAMIC	220P J	50V	C5713	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5588	CK1A105KLZBNG	CERAMIC	1U K	10V	C5750	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5589	CK1A105KLZBNG	CERAMIC	1U K	10V	C5751	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V
C5590	CK1A105KLZBNG	CERAMIC	1U K	10V	C5752	CEXLB0J221VEN	ELECT	220U M	6.3V
C5591	CK1A105KLZBNG	CERAMIC	1U K	10V	C5800	CC1H680JLZCNG	CERAMIC	68P J	50V
C5592	CK1A105KLZBNG	CERAMIC	1U K	10V	C5801	CC1H680JLZCNG	CERAMIC	68P J	50V
C5593	CK1A105KLZBNG	CERAMIC	1U K	10V	C5802	CC1H680JLZCNG	CERAMIC	68P J	50V
C5594	CK1A105KLZBNG	CERAMIC	1U K	10V	C5803	CC1H270JLZCNG	CERAMIC	27P J	50V
C5595	CK1A105KLZBNG	CERAMIC	1U K	10V					

Schematic Location	Part No.	Des	cription			Schematic Location	Part No.	Des	scription	
C5804	CC1H270JLZCNG	CERAMIC	27P J	50V	•	C6706	CEXLB0J102VEN	ELECT	1000U M	6.3V
C5805	CC1H270JLZCNG	CERAMIC	27P J	50V		SC1000	CC1H150JLZCNG	CERAMIC	15P J	50V
C5806	CC1H150JLZCNG	CERAMIC	15P J	50V		SC1001	CC1H150JLZCNG	CERAMIC	15P J	50V
C5807	CC1H150JLZCNG	CERAMIC	15P J	50V		SC1003	CC1H150JLZCNG	CERAMIC	15P J	50V
C5808	CC1H150JLZCNG	CERAMIC	15P J	50V		SC2400	CC1H221JLZCNG	CERAMIC	220P J	50V
C5809	CC1H120JLZCNG	CERAMIC	12P J	50V		SC2401	CC1H221JLZCNG	CERAMIC	220P J	50V
C5810	CC1H120JLZCNG	CERAMIC	12P J	50V						
C5811	CC1H120JLZCNG	CERAMIC	12P J	50V			DIODEO			
C5812	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V			DIODES			
C5813	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		D017	DDSS3P3-E3—G	DIODE SS3P		
C5814	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		D020	DDSS3P3-E3—G	DIODE SS3P		
C5815	CK1H104KLZBNG	CERAMIC	0.1U K	50V		D801	DZ02DZ3.9Y—G		)E 02DZ3.9Y(	TPH3
C5816	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V			DZUDZS3.9B—G	ZD UDZS-TE		_
C5817	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V			DZXLBXB3.9B-G		E MM3Z3V9	
C5901	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		D1620	DZ02DZ3.0Y—G		E 02DZ3.0Y(	•
C5902	CK1E224KLZBNG	CERAMIC	0.22U K	25V			DZUDZS3.0B—G		E UDZS3.0B	
C6100	CK1H102KLZBNG	CERAMIC	1000P K	50V			DZXLBXB3.0B-G		DE MM3Z3V0	В
C6102	CC1H270JLZCNG	CERAMIC	27P J	50V		D1621	DD1SS352G	DIODE 1SS3		
C6103	CC1H270JLZCNG	CERAMIC	27P J	50V			DD1SS355G	DIODE 1SS3		
C6104	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		D.10.10	DDXLBB053—-G	DIODE 1SS3		
C6105	CEXLB0J221VDN	ELECT	220U M	6.3V		D1640	DDSS3P3-E3—G	DIODE SS3F		
C6107	CEXLB1C102VDN	ELECT	1000U M	16V		D1670	DD1SS352G	DIODE 1SS3		
C6108	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V			DD1SS355G	DIODE 1SS3		
C6111	CK1H102KLZBNG	CERAMIC	1000P K	50V		D.100.1	DDXLBB053—-G	DIODE 1SS3		
C6112	RGFR000ZTCANL	MT-GLAZE	0.000 ZA			D1684	DD1SS352G	DIODE 1SS3		
C6113	RGFR000ZTCANL	MT-GLAZE	0.000 ZA				DD1SS355G	DIODE 1SS3		
C6250	CK0J475KLZBNG	CERAMIC	4.7U K			D4700	DDXLBB053—-G	DIODE 1SS3		
C6251	CEXLB1V470VEN	ELECT	47U M	35V		D1762	DD1SS352G	DIODE 1SS3		
C6252	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V			DD1SS355G	DIODE 1883		
C6253	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V		D0.400	DDXLBB053—-G	DIODE 1SS3		,
C6254	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V		D2403	DDRB551V-30-G		51V-30-TE-17	
C6255	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V		D2404	DDRB551V-30-G	DIODE RB55	51V-30-TE-17	
C6270	CK0J475KLZBNG	CERAMIC	4.7U K	6.3V						
C6271	CEXLB1V470VEN	ELECT	47U M	35V			INTEGRATE	D CIRCUI	TS	
C6272	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		IC001	QLV49152V-E-P	IC LV49152\		
C6273	CK0J475KLZBNG	CERAMIC	4.7U K			IC025	QTC7SET08FU-P	IC TC7SET08		
C6274	CK0J475KLZBNG	CERAMIC	4.7U K			IC025	QXXAVC924—-P	IC 74AHCT1		
C6275	CK0J475KLZBNG	CERAMIC	4.7U K			IC800	QXXAAJQ1239—		32AVU-Y10L0	CD
C6300	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		IC800A	QXXGA0500125M		32AVU-QIP-E	
C6301	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V		IC803	QLE24C023M-EP	IC LE24C023		
C6302	CK1H104ZLZFNG	CERAMIC	0.1U Z	50V			QXXAVC837—-P		BN-10SU-1.8	
C6303	CEXLB1C221VEN	ELECT	220U M	16V			QXXAVC986P	IC CAT24C0	2WI-GT3	
C6304	CEXLB1V470VEN	ELECT	47U M	35V 50V		IC905	QTC7SET08FU-P	IC TC7SET08	BFU-(TE85L)	
C6305 C6382	CK1H104ZLZFNG CK1A105KLZBNG	CERAMIC	0.1U Z 1U K				QXXAVC924—-P	IC 74AHCT1	G08GW	
C6500		CERAMIC	0.1U Z	10V 50V		IC1620	QLM1117S-ADJP	IC LM1117S	-ADJ	
C6500	CK1H104ZLZFNG CK1H104ZLZFNG	CERAMIC CERAMIC	0.10 Z 0.1U Z	50V		IC1640	QLV5803M-E-P	IC LV5803M	-TE-L-E	
C6550						IC1670	QLM1117S-ADJP	IC LM1117S	-ADJ	
C6551	CK1H104ZLZFNG CK1H104ZLZFNG	CERAMIC CERAMIC	0.1U Z 0.1U Z	50V 50V		IC2401	Q74AHC1G08GWP	IC 74AHC1G	08GW	
C6600	CK1H104ZLZFNG	CERAMIC	0.10 Z 0.1U Z	50V			QTC7SH08FU—P	IC TC7SH08	FU(TE85L)	
C6601	CK1H104ZLZFNG CK1A105KLZBNG	CERAMIC	0.10 Z 1U K	10V		IC2402	Q74AHC1G08GWP	IC 74AHC1G	` ,	
C6602	CEXLB1C471VDN	ELECT	470U M	16V			QTC7SH08FU—P	IC TC7SH08	FU(TE85L)	
C6701	CK1A105KLZBNG	CERAMIC	4700 M 1U K	10V		IC2403	QLE24C023M-EP	IC LE24C023		
C6701 C6702	CK1H104KLZBNG	CERAMIC	0.1U K	50V			QXXAVC837—-P		BN-10SU-1.8	
C6702	CK1A105KLZBNG	CERAMIC	1U K	10V			QXXAVC986—-P	IC CAT24C0	2WI-GT3	
C6703 C6705				6.3V		IC2440	Q74AHC1G08GWP	IC 74AHC1G	08GW	
00/00	CEXLB0J221VEN	ELECT	220U M	0.37						

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
	QTC7SH08FU—P	IC TC7SH08FU(TE85L)	L5509	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
IC2445	Q74AHC1G08GWP	IC 74AHC1G08GW	L5510	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"
	QTC7SH08FU—P	IC TC7SH08FU(TE85L)	L5511	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"
IC5500	QXXAVD108—-M	IC ZR39772HGCF-B	L5512	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC5700	QXXAVD132—-M	IC H5PS5162FFR-25C	L5513	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC5750	QXXAAJQ1243—	IC NAND128W3A2BM6E	L5514	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"
IC5750A	QXXAVC973—-M	IC NAND128W3A2BN6E	L5515	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"
IC5900	QXXAVD046P	IC XC6108N28AMR	L5517	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC6250	QBA4558RF-E2P	IC BA4558RF-E2	L5518	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
	QNJM4558M—-P	IC NJM4558M-TE2	L5519	1AV4L26B1940G	"INDUCTOR,120 OHM"
IC6270	QBA4558RF-E2P	IC BA4558RF-E2	L5519	1LB4L26B0700G	"INDUCTOR, 120 OHM"
	QNJM4558M—-P	IC NJM4558M-TE2	L5750	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC6500	QTC7SET08FU-P	IC TC7SET08FU-(TE85L)	L5800	1AV4L2GA150JG	"INDUCTOR,15U J"
	QXXAVC924—-P	IC 74AHCT1G08GW	L5801	1AV4L2GA150JG	"INDUCTOR,15U J"
IC6550	QTC7SET08FU-P	IC TC7SET08FU-(TE85L)	L5802	1AV4L2GA150JG	"INDUCTOR,15U J"
	QXXAVC924—-P	IC 74AHCT1G08GW	L5803	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC6600	QRT9711CGB—P	IC RT9711CGB	L6100	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
IC6700	QPQ070XNA1ZPP	IC PQ070XNA1ZPH	L6101	1AV4L26B1940G	"INDUCTOR,120 OHM"
			L6101	1LB4L26B0700G	"INDUCTOR, 120 OHM"
	0011.0		L6102	1AV4L26B1940G	"INDUCTOR,120 OHM"
	COILS	<b>"</b>	L6102	1LB4L26B0700G	"INDUCTOR , 120 OHM"
L011	1LB4L26B1630G	"INDUCTOR ,22UH"	L6103	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"
L012	1LB4L26B1630G	"INDUCTOR ,22UH"	L6250	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
L013	1LB4L26B1630G	"INDUCTOR ,22UH"	L6270	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
L014	1LB4L26B1630G	"INDUCTOR ,22UH"	L6302	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
L800	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"	L6303	1LB4L26B0740G	"INDUCTOR , 220 OHM"
L1610	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6304	1AV4L3CY201MG	"IMPEDANCE,200 OHM M"
L1611	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6305	1AV4L3CY201MG	"IMPEDANCE,200 OHM M"
L1620	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6306	1AV4L3CY201MG	"IMPEDANCE,200 OHM M"
L1621	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6550	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
L1641	1LB4L26B1180G	INDUCTOR 10U M	L6700	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W
L1644	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6702	1LB4L26B0740G	"INDUCTOR, 220 OHM"
L1676 L1677	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W MT-GLAZE 0.000 ZA 1/10W	L6705	1LB4L26B0740G	"INDUCTOR, 220 OHM"
L1677 L1682	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6706	1LB4L26B0740G	"INDUCTOR, 220 OHM"
L1683	RGFR000ZTAANL RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	L6707	1LB4L26B0740G	"INDUCTOR, 220 OHM"
L1684	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W			
L1685	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W		<b>RESISTORS</b>	
L1702	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W	R009	RGF2201JTCANL	MT-GLAZE 2.2K JA 1/10W
L1702	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R010	RGF2201JTCANL	MT-GLAZE 2.2K JA 1/10W
L1706	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R011	RGF2201JTCANL	MT-GLAZE 2.2K JA 1/10W
L1708	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R013	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
L1709	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R014	RGF2201JTCANL	MT-GLAZE 2.2K JA 1/10W
L1710	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R015	RGF5601FTCANL	MT-GLAZE 5.6K FA 1/10W
L1711	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R016	RGF1501FTCANL	MT-GLAZE 1.5K FA 1/10W
L1725	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R021	RGF2R70JTCANL	MT-GLAZE 2.7 JA 1/10W
L1831	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W	R022	RGF2R70JTCANL	MT-GLAZE 2.7 JA 1/10W
L2400	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R024	RGF1002JTCANL	MT-GLAZE 10K JA 1/10W
L5500	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R025	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
L5501	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W	R028	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
L5503	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R030	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
L5504	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R800	RGF4700JTCANL	MT-GLAZE 470 JA 1/10W
L5505	1AV4L2FB3R3MG	"INDUCTOR,3.3U M"	R801	RGF2202JTCANL	MT-GLAZE 22K JA 1/10W
L5506	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W	R802	RGF1002JTCANL	MT-GLAZE 10K JA 1/10W
L5507	1AV4L2GAR22JG	"INDUCTOR,0.22U J"	R804	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W
L5508	RGFR000ZTAANL	MT-GLAZE 0.000 ZA 1/10W	R807	RGFR000ZTCANL	MT-GLAZE 0.000 ZA 1/10W

R808   R6F100JTCANL   MT-GLAZE   00.00 ZA 170W   R901   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R912   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R913   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R913   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R915   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R916   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R916   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R917   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R918   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R919   R6F100JTCANL   MT-GLAZE   10.0 JA 170W   R919   R6F100JTCANL   MT-GLAZE   0.000 ZA 170W   R919   R6F20DGTCANL   MT-GLAZE   0.000 ZA 170	Schematic Location	Part No.	Des	cription	Schem Locatio	I Part No	Des	scription
R816   R6F2001TCANL   MT-GLAZE   22.X   A 170W   R905   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R817   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R817   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R818   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R819   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R828   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R829   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R830   R6F3002TCANL   MT-GLAZE   0.000 ZA 170W   R832   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R834   R6F8002TCANL   MT-GLAZE   0.000 ZA 170W   R834   R6F8002TCANL   MT-GLAZE   0.000 ZA 170W   R837   R6F8002TCANL   MT-GLAZE   0.000 ZA 170W   R837   R6F8002TCANL   MT-GLAZE   0.000 ZA 170W   R837   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R838   R6F1002TCANL   MT-GLAZE   0.000 ZA 170W   R839   R6F1002TCANL   MT-GLAZE   0.	R808	RGF1001JTCANL		1K JA 1/10W			MT-GLAZE	100 JA 1/10W
R817 R6F0002TCANL	R809	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R90	2 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R817   R6F1002/ITCANL   MT-GLAZE   10K.JA 1/10W   R910   R6FR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R823   R6F1002/ITCANL   MT-GLAZE   10K.JA 1/10W   R911   R6FR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R827   R6F1002/ITCANL   MT-GLAZE   10K.JA 1/10W   R910   R6F2000/ITCANL   MT-GLAZE   220 JA 1/10W   R828   R6F1002/ITCANL   MT-GLAZE   10K.JA 1/10W   R1000   R6F2200JTCANL   MT-GLAZE   220 JA 1/10W   R829   R6F1002/ITCANL   MT-GLAZE   10K.JA 1/10W   R1000   R6F2200JTCANL   MT-GLAZE   82 JA 1/10W   R830   R6F3033JTCANL   MT-GLAZE   30K.JA 1/10W   R1007   R6F280DJTCANL   MT-GLAZE   82 JA 1/10W   R831   R6F100JTCANL   MT-GLAZE   100 JA 1/10W   R1010   R6F280DJTCANL   MT-GLAZE   82 JA 1/10W   R832   R6F100JTCANL   MT-GLAZE   100 JA 1/10W   R1010   R6F280DJTCANL   MT-GLAZE   82 JA 1/10W   R833   R6F100JTCANL   MT-GLAZE   100 JA 1/10W   R1016   R6F780DJTCANL   MT-GLAZE   100 JA 1/10W   R1017   R6F280JTCANL   MT-GLAZE   100K JA 1/10W   R1018   R6F160JJTCANL   MT-GLAZE   100K JA 1/10W   R1018   R6F160JJTCANL   MT-GLAZE   100K JA 1/10W   R1019   R6F280JTCANL   MT-GLAZE   100K JA 1/10W   R1018   R6F160JJTCANL   MT-GLAZE   100K JA 1/10W   R1018   R6F160JJTCANL   MT-GLAZE   100K JA 1/10W   R1019   R6F280JTCANL   MT-GLAZE   100K JA 1/10W   R1021   R6F100JJTCANL   MT-GLAZE   100K	R813	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R90	3 RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R820   RGFR00ZTCANL	R816	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W	R90	5 RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
R827   RGF1001/ICANL   MT-GLAZE   1K.JA 1/10W   R100   RGF22001/CANL   MT-GLAZE   220.4 1/10W   R828   RGF1002/ICANL   MT-GLAZE   10K.JA 1/10W   R1004   RGF22001/CANL   MT-GLAZE   220.4 1/10W   R829   RGF1002/ICANL   MT-GLAZE   10K.JA 1/10W   R1004   RGF22001/CANL   MT-GLAZE   82.JA 1/10W   R830   RGF30303/ICANL   MT-GLAZE   10K.JA 1/10W   R1004   RGF22001/CANL   MT-GLAZE   82.JA 1/10W   R831   RGF10001/CANL   MT-GLAZE   10U.JA 1/10W   R1010   RGF22001/CANL   MT-GLAZE   0.000 ZA 1/10W   R832   RGF10001/CANL   MT-GLAZE   10U.JA 1/10W   R1011   RGF7/RDJ1/CANL   MT-GLAZE   220.4 1/10W   R833   RGF10001/CANL   MT-GLAZE   10U.JA 1/10W   R1016   RGF1603/ICANL   MT-GLAZE   220.4 1/10W   R836   RGF10001/CANL   MT-GLAZE   10U.JA 1/10W   R1016   RGF1603/ICANL   MT-GLAZE   220.4 JA 1/10W   R836   RGF1003/ICANL   MT-GLAZE   10U.JA 1/10W   R1018   RGF1603/ICANL   MT-GLAZE   220K JA 1/10W   R837   RGF1003/ICANL   MT-GLAZE   10UK JA 1/10W   R1018   RGF1603/ICANL   MT-GLAZE   220K JA 1/10W   R838   RGF1003/ICANL   MT-GLAZE   10UK JA 1/10W   R1024   RGF1003/ICANL   MT-GLAZE   220K JA 1/10W   R839   RGF1003/ICANL   MT-GLAZE   10UK JA 1/10W   R1024   RGF1003/ICANL   MT-GLAZE   220K JA 1/10W   R1024   RGF1003/ICANL   MT-GLAZE   220K JA 1/10W   R1024   RGF1003/ICANL   MT-GLAZE   220K JA 1/10W   R1024   RGF1003/ICANL   MT-GLAZE	R817	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R90	8 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R827   R6F1002JTCANIL   MT-GLAZE   10K JA 1/10W   R1000   R6F82R0JTCANIL   MT-GLAZE   22.0 A 1/10W   R1097   R6F82R0JTCANIL   MT-GLAZE   22.0 A 1/10W   R1097   R6F82R0JTCANIL   MT-GLAZE   82.0 A 1/10W   R1098   R6F800JTCANIL   MT-GLAZE   82.0 A 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100.0 A 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100.0 A 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100.0 A 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100K JA 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100K JA 1/10W   R1091   R6F82R0JTCANIL   MT-GLAZE   100K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   200K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   200K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   200K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   100K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   100K JA 1/10W   R1092   R6F300JTCANIL   MT-GLAZE   100K JA 1/10W   R1092   R6F100JTCANIL   MT-GLAZE   100K JA 1/10W   R1092   R6F300JTCANIL   MT-GLAZE   100K JA 1/10W   R1093   R6F800DTCANIL   MT-GLAZE   100K JA 1/10W   R1093   R6F800DTCANIL   MT-GLAZE   100K JA 1/10W   R1093   R6F800DTCANIL   MT-GLAZE   100K JA 1/10W   R1094   R6F100JTCANIL   MT-GLAZE   100K JA 1/10W	R820	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R91	0 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R828   RGF1002LTCANIL   MT-GLAZE   10K JA 1/10W   R1007   CG1H680LIZCNG   CERAMIC   68P J 50V   R830   RGF3003LTCANIL   MT-GLAZE   330K JA 1/10W   R1009   RGFR000ZTCANIL   MT-GLAZE   230K JA 1/10W   R1010   RGFR00DZTCANIL   MT-GLAZE   230K JA 1/10W   R1011   RGF78RDLTCANIL   MT-GLAZE   75 JA 1/10W   R1033   RGF1000LTCANIL   MT-GLAZE   100 JA 1/10W   R1016   RGF1603LTCANIL   MT-GLAZE   75 JA 1/10W   R1038   RGF100ALTCANIL   MT-GLAZE   100 JA 1/10W   R1018   RGF1603LTCANIL   MT-GLAZE   220K JA 1/10W   R1038   RGF1603LTCANIL   MT-GLAZE   100 JA 1/10W   R1018   RGF1603LTCANIL   MT-GLAZE   220K JA 1/10W   R1038   RGF100ALTCANIL   MT-GLAZE   100K JA 1/10W   R1018   RGF1603LTCANIL   MT-GLAZE   100K JA 1/10W   R1020   RGF100ALTCANIL   MT-GLAZE   100K JA 1/10W   R1021   RGF100ALTCANIL   MT-GLAZE   100J JA 1/10W   R1021   RGF100ALTCANIL   MT-GLAZE   100J JA 1/10W   R1021   RGF100ALTCANIL   MT-GLAZE   100J JA 1/10W   R1023   RGF300ALTCANIL   MT-GLAZE   100J JA 1/10W   R1023   RGF300ALTCANIL   MT-GLAZE   30K JA 1/10W   R1024   RGF100ALTCANIL   MT-GLAZE   100J JA 1/10W   R1024   RGF100ALTCANIL   MT-GLAZE   30K JA 1/10W   R1024   RGF100ALTCANIL   MT-GLAZE   20K JA 1/	R823	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W	R91	1 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R829	R827	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10	00 RGF2200JTCANL	MT-GLAZE	220 JA 1/10W
R830	R828	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10	04 RGF82R0JTCANL	MT-GLAZE	82 JA 1/10W
R831   RGF1000JTCANL	R829	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10	07 CC1H680JLZCNG	CERAMIC	68P J 50V
R832   RGF1000JTCANL	R830	RGF3303JTCANL	MT-GLAZE	330K JA 1/10W	R10	09 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R833         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1016         RGF1503JTCANL         MT-GLAZE         2000 ZA 1/10W           R836         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1018         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R837         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W         R1019         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R838         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W         R1029         RGF1000JTCANL         MT-GLAZE         20K JA 1/10W           R840         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1022         RGF1300JTCANL         MT-GLAZE         100 JA 1/10W           R841         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1023         RGF3303JTCANL         MT-GLAZE         30K JA 1/10W           R842         RGF100DJTCANL         MT-GLAZE         100 JA 1/10W         R1031         RGFR00ZTCANL         MT-GLAZE         30K JA 1/10W           R843         RGF470JTCANL         MT-GLAZE         4.7K JA 1/10W         R1042         RGF1503JTCANL         MT-GLAZE         50K JA 1/10W           R845         RGF470JTCANL         MT-GLAZE         4.7K JA 1/10W         R1042<	R831	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	10 RGF82R0JTCANL	MT-GLAZE	82 JA 1/10W
R834   RGFR000ZTCANL	R832	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	11 RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R836   RGF100JTCANL   MT-GLAZE   100 JA 1/10W   R1018   RGF160JJTCANL   MT-GLAZE   200 JA 1/10W   R1037   RGF100JJTCANL   MT-GLAZE   200 JA 1/10W   R1091   RGF220JJTCANL   MT-GLAZE   200 JA 1/10W   R1020   RGF100JJTCANL   MT-GLAZE   100 JA 1/10W   R1021   RGF100JJTCANL   MT-GLAZE   100 JA 1/10W   R1021   RGF100JJTCANL   MT-GLAZE   100 JA 1/10W   R1021   RGF100JJTCANL   MT-GLAZE   300 JA 1/10W   R1021   RGF30JJTCANL   MT-GLAZE   300 JA 1/10W   R1022   RGF330JJTCANL   MT-GLAZE   330 JA 1/10W   R841   RGF100JJTCANL   MT-GLAZE   100 JA 1/10W   R1023   RGF30JJTCANL   MT-GLAZE   330 JA 1/10W   R842   RGF100JJTCANL   MT-GLAZE   100 JA 1/10W   R1031   RGFR00DZTCANL   MT-GLAZE   330 JA 1/10W   R1042   RGF100JJTCANL   MT-GLAZE   300 JA 1/10W   R1041   RGFR00DZTCANL   MT-GLAZE   0.000 ZA 1/10W   R1041   RGF100JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1041   RGF10JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1042   RGF10JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1043   RGF20JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1043   RGF20JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1043   RGF20JJTCANL   MT-GLAZE   0.000 ZA 1/10W   R1044   RGF150JJTCANL   MT-GLAZE   150K JA 1/10W   R1045   RGF220JJTCANL   MT-GLAZE   22K JA 1/10W   R1045   RGF220JJTCANL   MT-GLAZE   22K JA 1/10W   R1045   RGF220JJTCANL   MT-GLAZE   150K JA 1/10W   R1045   RGF10JJTCANL   MT-GLAZE   150K JA 1/10W   R1045   RGF220JJTCANL   MT-GLAZE   150K JA 1/10W   R1045   RGF100JJTCANL   MT-GLAZE   150K JA 1/10W   R1045   RGF100JJTCANL   MT-GLAZE   150K JA 1/10W   R1050   RGF470JJTCANL   MT-GLAZE   100 JA 1/10W   R1050   RGF470JJTCANL   MT-GLAZE   100 JA 1/10W   R1050   RGF470JJTCANL   MT-G	R833	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	16 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R837         RGF1003JTCANL MT-GLAZE         MT-GLAZE 100K JA 1/10W         R1019 R10Q         RGF2203JTCANL R6F1000JTCANL MT-GLAZE         MT-GLAZE 100 JA 1/10W         200 A 1/10W         RGF2203JTCANL R6F1000JTCANL MT-GLAZE         MT-GLAZE 100 JA 1/10W         A1/10W R1022         RGF1000JTCANL R6F1000JTCANL MT-GLAZE         MT-GLAZE 100 JA 1/10W MT-GLAZE         MT-GLAZE 100 JA 1/10W R1033         RGF1000JTCANL R6F300JTCANL MT-GLAZE         MT-GLAZE 100 JA 1/10W R1033         MT-GLAZE R6F300JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1033         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1043         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1044         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1044         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1045         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1046         MT-GLAZE R6F100JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1046         MT-GLAZE R6F200JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1048         MT-GLAZE R6F200JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1048         MT-GLAZE R6F200JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R1049         MT-GLAZE R6F200JTCANL MT-GLAZE         MT-GLAZE 0.000 ZA 1/10W R	R834	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R10	17 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R838   RGF1003JTCANL   MT-GLAZE   100K JA 1/10W   R1020   RGF1000JTCANL   MT-GLAZE   100 JA 1/10W   R1021   RGF1000JTCANL   MT-GLAZE   30K JA 1/10W   R104   RGF1000JTCANL   MT-GLAZE   30K JA 1/10W   R104   RGF1000JTCANL   MT-GLAZE   30K JA 1/10W   R104   RGF300JTCANL   MT-GLAZE   30K JA 1/10W   R1031   RGFR000ZTCANL   MT-GLAZE   30K JA 1/10W   R1031   RGFR000ZTCANL   MT-GLAZE   30K JA 1/10W   R104   RGF400JTCANL   MT-GLAZE   4.7K JA 1/10W   R104   RGF100JTCANL   MT-GLAZE   100 JA 1/10W   R104   RGF100JTCANL   MT-GLAZE   100 JA 1/10W   R104   RGF100JTCANL   MT-GLAZE   150K JA 1/10W   R104   RGF100JTCANL   MT-GLAZE   22K JA 1/10W   R104   RGF100JTCANL   MT-GLAZE   22K JA 1/10W   R104   RGF120JTCANL   MT-GLAZE   220K JA 1/10W   R105   RGF100JTCANL   MT-GLAZE   220K JA 1/10W   R105   RGF470JTCANL   MT-GLAZE   220K JA 1/10W   R105   RGF100JTCANL   MT-GLAZE   220K	R836	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	18 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R839   RGF1003JTCANL   MT-GLAZE   100K JA 1/10W   R1021   RGF1000JTCANL   MT-GLAZE   330K JA 1/10W   R841   RGF1000JTCANL   MT-GLAZE   100 JA 1/10W   R1022   RGF3303JTCANL   MT-GLAZE   330K JA 1/10W   R842   RGF1000JTCANL   MT-GLAZE   100 JA 1/10W   R1031   RGF8000ZTCANL   MT-GLAZE   330K JA 1/10W   R843   RGF470JTCANL   MT-GLAZE   100 JA 1/10W   R1031   RGF8000ZTCANL   MT-GLAZE   100 JA 1/10W   R1033   RGF8000ZTCANL   MT-GLAZE   100 JA 1/10W   R1033   RGF8000ZTCANL   MT-GLAZE   150K JA 1/10W   R845   RGF470JJTCANL   MT-GLAZE   2.000 ZA 1/10W   R1043   RGF2203JTCANL   MT-GLAZE   150K JA 1/10W   R1044   RGF1503JTCANL   MT-GLAZE   220K JA 1/10W   R846   RGF470JJTCANL   MT-GLAZE   22UK JA 1/10W   R1044   RGF1503JTCANL   MT-GLAZE   220K JA 1/10W   R850   RGF1002JTCANL   MT-GLAZE   10K JA 1/10W   R1045   RGF2203JTCANL   MT-GLAZE   220K JA 1/10W   R851   RGF1002JTCANL   MT-GLAZE   10K JA 1/10W   R1045   RGF2203JTCANL   MT-GLAZE   220K JA 1/10W   R1045   RGF1503JTCANL   MT-GLAZE   220K JA 1/10W   R852   RGF4700JTCANL   MT-GLAZE   10K JA 1/10W   R1047   RGF2203JTCANL   MT-GLAZE   150K JA 1/10W   R852   RGF4700JTCANL   MT-GLAZE   10K JA 1/10W   R1048   RGF1503JTCANL   MT-GLAZE   220K JA 1/10W   R854   RGF220JTCANL   MT-GLAZE   22K JA 1/10W   R1049   RGF2203JTCANL   MT-GLAZE   220K JA 1/10W   R854   RGF220JTCANL   MT-GLAZE   22K JA 1/10W   R1050   RGF4700JTCANL   MT-GLAZE   220K JA 1/10W   R1051   RGF4700JTCANL   MT-GLAZE   220K JA 1/10W   R1052   RGF100JTCANL   MT-GLAZE   220K JA 1/10W   R1052   RGF100JTCANL   MT-GLAZE   220K JA 1/10W   R1053   RGF100JTCANL   MT-GLAZE   10J JA 1/10W   R1054   RGF100JTCANL   MT-GLAZE   10J JA 1/10W   R1056   RGF100JTCANL   MT-GLAZE   10J JA 1/10W   R1056   RGF100JTCANL   MT-GLAZE   10J JA 1/	R837	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W	R10	19 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R840   RGFR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R1022   RGF3303JTCANL   MT-GLAZE   330K JA 1/10W   R841   RGF1000JTCANL   MT-GLAZE   100 JA 1/10W   R1031   RGF3003JTCANL   MT-GLAZE   330K JA 1/10W   R843   RGF1000JTCANL   MT-GLAZE   100 JA 1/10W   R1031   RGFR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R844   RGFR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R1033   RGFR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R844   RGFR000ZTCANL   MT-GLAZE   0.000 ZA 1/10W   R1042   RGF1503JTCANL   MT-GLAZE   2.000 ZA 1/10W   R845   RGF470JJTCANL   MT-GLAZE   4.7K JA 1/10W   R1043   RGF2203JTCANL   MT-GLAZE   220K JA 1/10W   R846   RGF470JJTCANL   MT-GLAZE   22K JA 1/10W   R1044   RGF1503JTCANL   MT-GLAZE   220K JA 1/10W   R847   RGF220ZJTCANL   MT-GLAZE   22K JA 1/10W   R1045   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1045   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1045   RGF1602JTCANL   MT-GLAZE   22K JA 1/10W   R1047   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1047   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1047   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1048   RGF1602JTCANL   MT-GLAZE   22K JA 1/10W   R1049   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1049   RGF2203JTCANL   MT-GLAZE   22K JA 1/10W   R1048   RGF1600JTCANL   MT-GLAZE   22K JA 1/10W   R1048   RGF1600JTCANL   MT-GLAZE   22K JA 1/10W   R1050   RGF470JJTCANL   MT-GLAZE   22K JA 1/10W   R1050   RGF470JJTCANL   MT-GLAZE   22K JA 1/10W   R1050   RGF470JJTCANL   MT-GLAZE   470 JA 1/10W   R1051   RGF470JJTCANL   MT-GLAZE   470 JA 1/10W   R1051   RGF470JJTCANL   MT-GLAZE   10M JA 1/10W   R1051   RGF100JTCANL   MT-GLAZE   10M JA 1/10W   R1051   RGF100JTCANL   MT-GLAZE   10	R838	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W	R10	20 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R841         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1023         RGF300JTCANL         MT-GLAZE         330K JA 1/10W           R842         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1031         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R844         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1042         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R845         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R846         RGF4701JTCANL         MT-GLAZE         24.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R847         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1045         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R853         RGF1000ZJTCANL         MT-GLAZE         10K JA 1/10W	R839	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W	R10	21 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R842         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1031         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R843         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1042         RGF1000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R844         RGF4701JTCANL         MT-GLAZE         0.000 ZA 1/10W         R1042         RGF1500JTCANL         MT-GLAZE         150K JA 1/10W           R846         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R850         RGF1002JTCANL         MT-GLAZE         22K JA 1/10W         R1044         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF4700JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF200ZJTCANL         MT-GLAZE         210K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W	R840	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R10	22 RGF3303JTCANL	MT-GLAZE	330K JA 1/10W
R843         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1033         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R844         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1043         RGF100JTCANL         MT-GLAZE         17/10W           R846         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         150K JA 1/10W           R847         RGF2202JTCANL         MT-GLAZE         22V JA 1/10W         R1045         RGF1503JTCANL         MT-GLAZE         22W JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R853         RGF1002JTCANL         MT-GLAZE         470 JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         10K JA 1/10W           R855         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048 </td <td>R841</td> <td>RGF1000JTCANL</td> <td>MT-GLAZE</td> <td>100 JA 1/10W</td> <td>R10</td> <td>23 RGF3303JTCANL</td> <td>MT-GLAZE</td> <td>330K JA 1/10W</td>	R841	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	23 RGF3303JTCANL	MT-GLAZE	330K JA 1/10W
R844         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1042         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R845         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         150K JA 1/10W           R847         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1044         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R850         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1047         RGF2203JTCANL         MT-GLAZE         150K JA 1/10W           R852         RGF4700JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R853         RGF4700JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         150K JA 1/10W           R854         RGF4700JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W <th< td=""><td>R842</td><td>RGF1000JTCANL</td><td>MT-GLAZE</td><td>100 JA 1/10W</td><td>R10</td><td>31 RGFR000ZTCANL</td><td>MT-GLAZE</td><td>0.000 ZA 1/10W</td></th<>	R842	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	31 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R845         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1043         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R846         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1044         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R847         RGF2202JTCANL         MT-GLAZE         220K JA 1/10W         R1045         RGF2003JTCANL         MT-GLAZE         150K JA 1/10W           R850         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF4700JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF200ZJTCANL         MT-GLAZE         22K JA 1/10W         R1059         RGF4700JTCANL         MT-GLAZE         22K JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         22K JA 1/10W         R1052         RGF100JTCANL         MT-GLAZE         470 JA 1/10W         R1052         RGF100JTCANL         MT-GLAZE         11/10W         R1053         RGF1	R843	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R10	33 RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R846         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1044         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R847         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1045         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R850         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1203JTCANL         MT-GLAZE         150K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1047         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1203JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF200JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF1001JTCANL         MT-GLAZE         170 JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053<	R844	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R10	42 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R847         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1045         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R850         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         220K JA 1/10W           R853         RGF100JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         25K JA 1/10W           R854         RGF220ZJTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         27K JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         27K JA 1/10W         R1051         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R867         RGF000ZTCANL         MT-GLAZE         100 JA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         100 JA 1/10W         R1055 <td>R845</td> <td>RGF4701JTCANL</td> <td>MT-GLAZE</td> <td>4.7K JA 1/10W</td> <td>R10</td> <td>43 RGF2203JTCANL</td> <td>MT-GLAZE</td> <td>220K JA 1/10W</td>	R845	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R10	43 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R850         RGF1002JTCANL R851         MT-GLAZE         10K JA 1/10W         R1046         RGF1503JTCANL R6F1002JTCANL MT-GLAZE         MT-GLAZE         10K JA 1/10W         R1047         RGF2203JTCANL R6F2203JTCANL MT-GLAZE         MT-GLAZE         220K JA 1/10W           R852         RGF4700JTCANL MT-GLAZE         MT-GLAZE         470 JA 1/10W         R1048         RGF1503JTCANL R6F2203JTCANL MT-GLAZE         MT-GLAZE         150K JA 1/10W           R854         RGF202JTCANL MT-GLAZE         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL RF470JTCANL MT-GLAZE         MT-GLAZE         22K JA 1/10W         R1051         RGF4700JTCANL RF470JTCANL MT-GLAZE         MT-GLAZE         470 JA 1/10W         R1051         RGF4700JTCANL RF470JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1051         RGF4700JTCANL RGF4700JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1052         RGF1000JTCANL RGF1000JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1052         RGF1000JTCANL RGF1000JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL RGF1000JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL RGF1000JTCANL MT-GLAZE         MT-GLAZE         100 JA 1/10W         R1056         RGF1000JTCANL RGF1000JTCANL MT-GLAZE	R846	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R10	44 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R851         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1047         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R852         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R853         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF100JJTCANL         MT-GLAZE         1K JA 1/10W           R858         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF100JJTCANL         MT-GLAZE         1K JA 1/10W           R867         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         1K JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         100 JA 1/10W         R1056 <td>R847</td> <td>RGF2202JTCANL</td> <td>MT-GLAZE</td> <td>22K JA 1/10W</td> <td>R10</td> <td>45 RGF2203JTCANL</td> <td>MT-GLAZE</td> <td>220K JA 1/10W</td>	R847	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W	R10	45 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R852         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W         R1048         RGF1503JTCANL         MT-GLAZE         150K JA 1/10W           R853         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         22K JA 1/10W           R854         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF4700JTCANL         MT-GLAZE         10 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R867         RGF8000ZTCANL         MT-GLAZE         100 JA 1/10W         R1054         RGF100JTCANL         MT-GLAZE         1K JA 1/10W           R868         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         100 JA 1/10W         R1057	R850	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10-	46 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R853         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1049         RGF2203JTCANL         MT-GLAZE         220K JA 1/10W           R854         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W         R1051         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1001JTCANL         MT-GLAZE         110 JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1000JTCANL         MT-GLAZE         110 JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1058         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1059 </td <td>R851</td> <td>RGF1002JTCANL</td> <td>MT-GLAZE</td> <td>10K JA 1/10W</td> <td>R10-</td> <td>47 RGF2203JTCANL</td> <td>MT-GLAZE</td> <td>220K JA 1/10W</td>	R851	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10-	47 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R854         RGF2202JTCANL         MT-GLAZE         22K JA 1/10W         R1050         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R856         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W         R1051         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF100JTCANL         MT-GLAZE         110 JA 1/10W           R858         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1000JTCANL         MT-GLAZE         110 JA 1/10W           R867         RGFR000ZTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100 JA 1/10W           R877         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058 <td>R852</td> <td>RGF4700JTCANL</td> <td>MT-GLAZE</td> <td>470 JA 1/10W</td> <td>R10-</td> <td>48 RGF1503JTCANL</td> <td>MT-GLAZE</td> <td>150K JA 1/10W</td>	R852	RGF4700JTCANL	MT-GLAZE	470 JA 1/10W	R10-	48 RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R856         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W         R1051         RGF4700JTCANL         MT-GLAZE         470 JA 1/10W           R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF1001JTCANL         MT-GLAZE         11K JA 1/10W           R858         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R866         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R867         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1059 <td>R853</td> <td>RGF1002JTCANL</td> <td>MT-GLAZE</td> <td>10K JA 1/10W</td> <td>R10-</td> <td>49 RGF2203JTCANL</td> <td>MT-GLAZE</td> <td>220K JA 1/10W</td>	R853	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R10-	49 RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
R857         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1052         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R858         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R867         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R868         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R877         RGF1002JTCANL         MT-GLAZE         100 JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100 JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         100 JA 1/10W         R1060 <td>R854</td> <td>RGF2202JTCANL</td> <td>MT-GLAZE</td> <td>22K JA 1/10W</td> <td>R10</td> <td></td> <td>MT-GLAZE</td> <td></td>	R854	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W	R10		MT-GLAZE	
R858         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1053         RGF1001JTCANL         MT-GLAZE         1K JA 1/10W           R867         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R868         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1069         RGF3303JTCANL         MT-GLAZE         100K JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R106	R856		MT-GLAZE	470 JA 1/10W	R10	51 RGF4700JTCANL		470 JA 1/10W
R867         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1054         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R868         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         10K JA 1/10W           R878         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         10D JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         10D JA 1/10W         R10		RGF1000JTCANL						
R868         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1055         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R871         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R881         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1	R858	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	53 RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R871         RGF4701JTCANL         MT-GLAZE         4.7K JA         1/10W         R1056         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W           R872         RGF4701JTCANL         MT-GLAZE         4.7K JA         1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA         1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100K JA         1/10W           R877         RGF1002JTCANL         MT-GLAZE         10K JA         1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA         1/10W           R878         RGF1000JTCANL         MT-GLAZE         4.7K JA         1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA         1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA         1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA         1/10W <td>R867</td> <td>RGFR000ZTCANL</td> <td>MT-GLAZE</td> <td>0.000 ZA 1/10W</td> <td>R10</td> <td>54 RGF1000JTCANL</td> <td>MT-GLAZE</td> <td>100 JA 1/10W</td>	R867	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R10	54 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R872         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1057         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGF8000ZTCANL         MT-GLAZE         47K JA 1/10W           R885         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W	R868	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	55 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R873         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1058         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R885         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         47K JA 1/10W           R887         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W	R871	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R10	56 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R874         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1059         RGF1003JTCANL         MT-GLAZE         100K JA 1/10W           R877         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1063         RGF8300JTCANL         MT-GLAZE         330K JA 1/10W           R885         RGF1000JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         12 JA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W         R1621         RGF1200FTCANL <td>R872</td> <td>RGF4701JTCANL</td> <td>MT-GLAZE</td> <td>4.7K JA 1/10W</td> <td>R10</td> <td>57 RGF1000JTCANL</td> <td>MT-GLAZE</td> <td>100 JA 1/10W</td>	R872	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R10	57 RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R877         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1060         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R878         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R885         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF1200FTCANL         MT-GLAZE         12 JA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W <t< td=""><td>R873</td><td>RGF1000JTCANL</td><td>MT-GLAZE</td><td>100 JA 1/10W</td><td>R10</td><td>58 RGF1003JTCANL</td><td>MT-GLAZE</td><td>100K JA 1/10W</td></t<>	R873	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R10	58 RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
R878         RGF4701JTCANL         MT-GLAZE         4.7K JA 1/10W         R1061         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R885         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W           R888         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R890         RGF8000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W <td< td=""><td></td><td>RGF1000JTCANL</td><td>MT-GLAZE</td><td>100 JA 1/10W</td><td></td><td></td><td></td><td>100K JA 1/10W</td></td<>		RGF1000JTCANL	MT-GLAZE	100 JA 1/10W				100K JA 1/10W
R879         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1062         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R885         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W           R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W <td< td=""><td></td><td></td><td>MT-GLAZE</td><td></td><td></td><td></td><td></td><td></td></td<>			MT-GLAZE					
R880         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W         R1063         RGF3303JTCANL         MT-GLAZE         330K JA 1/10W           R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R885         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W           R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W		RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W				
R883         RGF1002JTCANL         MT-GLAZE         10K JA 1/10W         R1614         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W           R885         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W           R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1643         RGF5601JTCANL         MT-GLAZE         5.6K JA 1/10W		RGF1000JTCANL	MT-GLAZE					
R885         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1615         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W           R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1643         RGF5601JTCANL         MT-GLAZE         5.6K JA 1/10W		RGF1000JTCANL	MT-GLAZE	100 JA 1/10W				
R887         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1620         RGF1200FTCANL         MT-GLAZE         120 FA 1/10W           R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         10K FA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1643         RGF5601JTCANL         MT-GLAZE         5.6K JA 1/10W		RGF1002JTCANL	MT-GLAZE	10K JA 1/10W				0.000 ZA 1/10W
R888         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1621         RGF12R0JTCANL         MT-GLAZE         12 JA 1/10W           R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1643         RGF5601JTCANL         MT-GLAZE         5.6K JA 1/10W		RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W				47K JA 1/10W
R890         RGFR000ZTCANL         MT-GLAZE         0.000 ZA 1/10W         R1622         RGF2200FTCANL         MT-GLAZE         220 FA 1/10W           R892         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1641         RGF1000JTCANL         MT-GLAZE         100 JA 1/10W           R896         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1642         RGF1002FTCANL         MT-GLAZE         10K FA 1/10W           R897         RGF4702JTCANL         MT-GLAZE         47K JA 1/10W         R1643         RGF5601JTCANL         MT-GLAZE         5.6K JA 1/10W		RGFR000ZTCANL						
R892 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1641 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R896 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1642 RGF1002FTCANL MT-GLAZE 10K FA 1/10W R897 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1643 RGF5601JTCANL MT-GLAZE 5.6K JA 1/10W								
R896 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1642 RGF1002FTCANL MT-GLAZE 10K FA 1/10W R897 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1643 RGF5601JTCANL MT-GLAZE 5.6K JA 1/10W								
R897 RGF4702JTCANL MT-GLAZE 47K JA 1/10W R1643 RGF5601JTCANL MT-GLAZE 5.6K JA 1/10W		RGF4702JTCANL						
		RGF4702JTCANL	MT-GLAZE					
R898 RGFR0007TCANI MT-GLA7F 0.000.7A 1/10W R1644 RGF6800FTCANI MT-GLA7F 680.FA 1/10W		RGF4702JTCANL	MT-GLAZE					
	R898	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W			MT-GLAZE	680 FA 1/10W
R899 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1645 RGF3301FTCANL MT-GLAZE 3.3K FA 1/10W		RGF1000JTCANL						
R900 RGF1000JTCANL MT-GLAZE 100 JA 1/10W R1670 RGF1200FTCANL MT-GLAZE 120 FA 1/10W	R900	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R16	70 RGF1200FTCANL	MT-GLAZE	120 FA 1/10W

Schematic Location	Part No.	Des	scription		Schematic Location	Part No.	De	scription
R1671	RGF12R0JTCANL	MT-GLAZE	12 JA 1/10W	•	R5522	RGF8200FTCANL	MT-GLAZE	820 FA 1/10W
R1672	RGF8200FTCANL	MT-GLAZE	820 FA 1/10W		R5524	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1685	RGFR000ZTAANL	MT-GLAZE	0.000 ZA 1/10W		R5526	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1686	RGFR000ZTAANL	MT-GLAZE	0.000 ZA 1/10W		R5527	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1687	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5529	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1688	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5531	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1690	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5532	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1700	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5538	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1701	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5539	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1702	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5540	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R1708	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5542	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R1765	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		R5543	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R1767 R1771	RGF1002JTCANL RGFR000ZTCANL	MT-GLAZE MT-GLAZE	10K JA 1/10W 0.000 ZA 1/10W		R5544 R5545	RGFR000ZTCANL RGF2201JTCANL	MT-GLAZE MT-GLAZE	0.000 ZA 1/10W 2.2K JA 1/10W
R1831	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W		R5546	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W 2.2K JA 1/10W
R2404	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5547	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R2405	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5548	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R2406	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5549	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2407	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W		R5550	RGF4702JTCANL	MT-GLAZE	47K JA 1/10W
R2408	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5551	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2411	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W		R5552	RGF3901JTCANL	MT-GLAZE	3.9K JA 1/10W
R2417	RGF1503JTCANL	MT-GLAZE	150K JA 1/10W		R5553	RGF3900FTCANL	MT-GLAZE	390 FA 1/10W
R2418	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		R5554	RGF3900FTCANL	MT-GLAZE	390 FA 1/10W
R2419	RGF1503JTCANL	MT-GLAZE	150K JA 1/10W		R5556	RGF1004JTCANL	MT-GLAZE	1M JA 1/10W
R2420	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W		R5557	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
R2421	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W		R5558	RGF1503JTCANL	MT-GLAZE	150K JA 1/10W
R2422	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5559	RGF3900JTCANL	MT-GLAZE	390 JA 1/10W
R2423	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5560	RGF8200FTCANL	MT-GLAZE	820 FA 1/10W
R2424	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W		R5561	RGF8200FTCANL	MT-GLAZE	820 FA 1/10W
R2425	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W		R5562	RGF27R0JTCANL	MT-GLAZE	27 JA 1/10W
R2426	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10W		R5563	RGF27R0JTCANL	MT-GLAZE	27 JA 1/10W
R2427	RGF3303JTCANL	MT-GLAZE	330K JA 1/10W		R5565	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2428	RGF3303JTCANL	MT-GLAZE	330K JA 1/10W		R5566	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2432	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5567	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2433	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5568	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R2440	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5571	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R2442 R2447	RGF1000JTCANL RGFR000ZTCANL	MT-GLAZE MT-GLAZE	100 JA 1/10W 0.000 ZA 1/10W		R5573 R5574	RGF4701JTCANL RGF4701JTCANL	MT-GLAZE MT-GLAZE	4.7K JA 1/10W 4.7K JA 1/10W
R2447	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5575	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W 4.7K JA 1/10W
R3300	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5576	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R3301	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5580	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5501	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5581	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5503	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5582	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5504	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W		R5583	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5505	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5584	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5506	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5585	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5507	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5586	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5508	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5587	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5512	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5591	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5513	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5592	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5514	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5597	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5515	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5598	RGF27R0FTCANL	MT-GLAZE	27 FA 1/10W
R5516	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W		R5599	RGF1000FTCANL	MT-GLAZE	100 FA 1/10W
R5517	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5600	RGF1000FTCANL	MT-GLAZE	100 FA 1/10W
R5518	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5601	RGF4700FTCANL	MT-GLAZE	470 FA 1/10W
R5520	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W		R5602	RGF8200FTCANL	MT-GLAZE	820 FA 1/10W

Schematic Location	Part No.	Des	cription	Schematic Location	Part No.	De	scription
R5603	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5818	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W
R5604	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W	R5819	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W
R5608	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5820	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W
R5613	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5821	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5614	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5822	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5616	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5823	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5618	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5827	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5620	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5828	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5622	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5829	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5624	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R5830	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5630	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R5831	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5631	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R5832	RGF4702JTCANL	MT-GLAZE	47K JA 1/10W
R5632	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5833	RGF4702JTCANL	MT-GLAZE	47K JA 1/10W
R5633	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W	R5834	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5635	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5835	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5640	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5836	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R5642	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5837	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R5643	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5838	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W
R5644	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R5900	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5645	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W	R5901	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5646	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R5902	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5647	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R5950	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5648	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R5952	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5649	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R5954	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5650	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R5956	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5651	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R5957	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5652	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R5960	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5653	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R6100	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5654	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R6101	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W
R5655	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R6250	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5656	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6251	RGF5601JTCANL	MT-GLAZE	5.6K JA 1/10W
R5657	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6252	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R5658	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6253	RGF6802JTCANL	MT-GLAZE	68K JA 1/10W
R5659	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6254	RGF6802JTCANL	MT-GLAZE	68K JA 1/10W
R5660	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6255	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R5661	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6271	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5662	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R6272	RGF5601JTCANL	MT-GLAZE	5.6K JA 1/10W
R5663	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R6273	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R5664	RGF10R0JTCANL	MT-GLAZE	10 JA 1/10W	R6274	RGF6802JTCANL	MT-GLAZE	68K JA 1/10W
R5665	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R6275	RGF6802JTCANL	MT-GLAZE	68K JA 1/10W
R5666	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W	R6276	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R5700	RGF1000FTCANL	MT-GLAZE	100 FA 1/10W	R6311	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5701	RGF1000JTCANL	MT-GLAZE	100 JA 1/10W	R6314	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5702	RGF1000FTCANL	MT-GLAZE	100 FA 1/10W	R6317	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5750	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R6318	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5752	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W	R6327	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W
R5778	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W	R6328	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W
R5803	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6331	RGF1504JTCANL	MT-GLAZE	1.5M JA 1/10W
R5804	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6332	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5805	RGF75R0JTCANL	MT-GLAZE	75 JA 1/10W	R6333	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R5806	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6334	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5807	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6336	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R5808	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6338	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R5812	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6380	RGF3300JTCANL	MT-GLAZE	330 JA 1/10W
R5814	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6382	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10W
R5816	RGF6800JTCANL	MT-GLAZE	680 JA 1/10W	R6386	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W

Schematic Location	Part No.	Des	scription	Schematic Location	Part No.	Description
R6390	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10	<u> </u>	TRANSISTO	RS
R6500	RGF2202JTCANL	MT-GLAZE	22K JA 1/10	W Q800	TISA1235AC1EP	TR ISA1235AC1E
R6501	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10		TISA1235AC1FP	TR ISA1235AC1F
R6502	RGF4702JTCANL	MT-GLAZE	47K JA 1/10	W	TXXLBB005—-P	TR MMBTSA1235F
R6503	RGF4702JTCANL	MT-GLAZE	47K JA 1/10	W Q804	TISA1235AC1EP	TR ISA1235AC1E
R6504	RGF1001JTCANL	MT-GLAZE	1K JA 1/10	W	TISA1235AC1FP	TR ISA1235AC1F
R6505	RGF1002JTCANL	MT-GLAZE	10K JA 1/10	W	TXXLBB005—-P	TR MMBTSA1235F
R6506	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10	W Q805	T2SC3928A1R-P	TR 2SC3928A1R
R6507	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6508	RGF1001JTCANL	MT-GLAZE	1K JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6509	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W Q806	T2SC3928A1R-P	TR 2SC3928A1R
R6510	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6511	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6512	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W Q1001	T2SC3928A1R-P	TR 2SC3928A1R
R6513	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6514	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6515	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W Q1002	T2SC3928A1R-P	TR 2SC3928A1R
R6516	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6517	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6520	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10	W Q1003	T2SC3928A1R-P	TR 2SC3928A1R
R6550	RGF2202JTCANL	MT-GLAZE	22K JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6551	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6552	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10	W Q1004	T2SC3928A1R-P	TR 2SC3928A1R
R6553	RGF4702JTCANL	MT-GLAZE	47K JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6554	RGF4702JTCANL	MT-GLAZE	47K JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6555	RGF1001JTCANL	MT-GLAZE	1K JA 1/10	W Q1005	T2SC3928A1R-P	TR 2SC3928A1R
R6556	RGF1002JTCANL	MT-GLAZE	10K JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6557	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10	W	TXXLBB006P	TR MMBTSC3928R
R6558	RGF47R0JTCANL	MT-GLAZE	47 JA 1/10	W Q1006	T2SC3928A1R-P	TR 2SC3928A1R
R6559	RGF1001JTCANL	MT-GLAZE	1K JA 1/10	W	T2SC3928A1S-P	TR 2SC3928A1S
R6560	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W	TXXLBB006—-P	TR MMBTSC3928R
R6561	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	W Q1007	T2SC3928A1R-P	TR 2SC3928A1R
R6562	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6563	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6564	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	۵.000	T2SC3928A1R-P	TR 2SC3928A1R
R6565	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6566	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6567	RGF4R70JTCANL	MT-GLAZE	4.7 JA 1/10	۵.0.0	TMCH6331-S-EG	TR MCH6331-S-TL-E
R6568	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10	41101	T2SC3928A1R-P	TR 2SC3928A1R
R6571	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6600	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6602	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10	W= .00	T2SC3928A1R-P	TR 2SC3928A1R
R6606	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6607	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6608	RGFR000ZTAANL	MT-GLAZE	0.000 ZA 1/10	Q_ 101	T2SC3928A1R-P	TR 2SC3928A1R
R6609	RGF2202JTCANL	MT-GLAZE	22K JA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6610	RGF2202JTCANL	MT-GLAZE	22K JA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6701	RGF2202JTCANL	MT-GLAZE	22K JA 1/10	~	T2SC3928A1R-P	TR 2SC3928A1R
R6702	RGFR000ZTCANL	MT-GLAZE	0.000 ZA 1/10		T2SC3928A1S-P	TR 2SC3928A1S
R6703	RGF4700FTCANL	MT-GLAZE	470 FA 1/10		TXXLBB006—-P	TR MMBTSC3928R
R6704	RGF1001FTCANL	MT-GLAZE	1K FA 1/10	40000	TISA1235AC1EP	TR ISA1235AC1E
RB1831	1LB4R1YB0R0ZG	R-NETWOR I		W	TISA1235AC1FP	TR ISA1235AC1F
RB5950	1LB4R1YB0R0ZG	R-NETWOR I		W	TXXLBB005—-P	TR MMBTSA1235F
RB6301	1LB4R1YB0R0ZG	R-NETWOR I		W Q5801	TISA1235AC1EP	TR ISA1235AC1E
RB6302	1LB4R1YB0R0ZG	R-NETWOR I	K UX4 0.06 3	W	TISA1235AC1FP	TR ISA1235AC1F
					TXXLBB005—-P	TR MMBTSA1235F

Schematic Location	Part No.	Description
Q5802	TISA1235AC1EP	TR ISA1235AC1E
	TISA1235AC1FP	TR ISA1235AC1F
	TXXLBB005—-P	TR MMBTSA1235F
Q5803	T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S
	TXXLBB006—-P	TR MMBTSC3928R
Q5804	T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S
	TXXLBB006—-P	TR MMBTSC3928R
Q5805	T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S
	TXXLBB006—-P	TR MMBTSC3928R
Q6301	T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S
	TXXLBB006—-P	TR MMBTSC3928R
Q6302	T2SC2411K-Q-P	TR 2SC2411K-T146-Q
Q6303	T2SC3928A1R-P	TR 2SC3928A1R
	T2SC3928A1S-P	TR 2SC3928A1S
	TXXLBB006—-P	TR MMBTSC3928R
Q6304	TMCH6331-S-EG	TR MCH6331-S-TL-E
Q6380	TISA1235AC1EP	TR ISA1235AC1E
	TISA1235AC1FP	TR ISA1235AC1F
	TXXLBB005—-P	TR MMBTSA1235F
Q6501	TUM6K1NP	TR UM6K1N-TN
	TUM6K1NP	TR UM6K1N-TN

Schematic Location	Part No.	Description
-----------------------	----------	-------------

# **CRYSTAL/FILTERS**

X5500	1AV4V10B9210G	"OSC,CRYSTAL 25MHZ"
X800	1AV4V11B1771G	"OSC,CERAMIC 8.00MHZ"
X801	1AV4V10B0560N	"OSC CRYSTAL 32 768KH7"

	ematic ation	Part No.	Description
		<b>MISCELLAN</b>	EOUS
<u> </u>	100	1AA0B10N271E0	"ASSY,PWB,MAIN_Z-N8MF"
<u> </u>	200	1AA0B10N28400	"ASSY,PWB,KEY_SW N8LF"
<u> </u>	300	1AA0B10N28500	"ASSY,PWB,RC_LED A N8LF"
<u> </u>	400	1AA0B10N29100	"ASSY,PWB,POWER N8LF"
ΔA	6100	1AV4F1BAZ0090	"TUNER,U/V"
E	L901	1AV4T40C17000	LCD(M260TWR1 R1)
El	L902	1AV4U20C46200	"UNIT,INVERTER"
K	1003	1LB4J31B01101	"TERMINAL, BOARD"
K	1004	1LB4J12B11700	"JACK,RCA-9"
K	1005	1LB4J12B11600	"JACK,RCA-6"
K	2400	1LB4J11B0630N	"SOCKET,D-SUB 15P"
K	2401	1LB4J12B11900	"JACK,PHONE D3.6"
K	5DL	1AV4J10AU045N	"PLUG,4P"
K	5LV	1AV4J10XE300G	"PLUG,30P"
K	6500	1AV4J11B8591G	"SOCKET,IF(HDMI) 19P"
K	6500	1LB4J11B0760G	"SOCKET,HDMI 19P"
K	6550	1AV4J11B8591G	"SOCKET,IF(HDMI) 19P"
K	6550	1LB4J11B0760G	"SOCKET,HDMI 19P"
K	802	1AV4J10EA053N	"PLUG,5P"
K	803	1AV4J10EA073N	"PLUG,7P"
K	8CTRA	1AV4J10AU035N	"PLUG,3P"
K	8C	1AV4J10FT130N	"PLUG,PWB 13P"
K	8FRA	1AV4J10EA063N	"PLUG,6P"
K	SP	1AV4J10EA043N	"PLUG,4P"
K	USB	1LB4J11B0550N	"SOCKET,USB 4P"
<b>∧</b> S	P901	1LB4A10B08704	"SPEAKER,8"
<b>∧</b> S	P902	1LB4A10B08704	"SPEAKER,8"
W	/901	1AV4W10B17903	"CORD,POWER-2.15MK-VTR-02"

WK5LV-PN 1LB4W30B21100 "CORD ,30P-30P(LVDS)"

Schematic Location Part No.	Description
-----------------------------	-------------

# **POWER BOARD PARTS LIST**

# **CAPACITORS**

	CAPACITOR	•		
C601	CKXAV2E101AAC	CERAMIC	100P M	250V
C605	CGXAV27474ABC	MT-POLYEST	0.47U M	275V
C605	CGXAV27474BBC	MT-POLYEST	0.47U K	275V
C606	CGXAV27224ABC	MT-POLYEST	0.22U M	275V
C606	CGXAV27224BBC	MT-POLYEST	0.22U K	275V
C608	CKXAV2E471AAC	CERAMIC	470P M	250V
C609	CGXAV27224ABC	MT-POLYEST	0.22U M	275V
C609	CGXAV27224BBC	MT-POLYEST	0.22U K	275V
C610	CK3A102KANHAN	CERAMIC	1000P K	1K
C611	CK3A102KANHAN	CERAMIC	1000P K	1K
C612	CK3A102KANHAN	CERAMIC	1000P K	1K
C613	CK3A102KANHAN	CERAMIC	1000P K	1K
C614	CEXAVB03000-N	ELECT	470U M	250V
C615	CK1E474KLZBNG	CERAMIC	0.47U K	25V
C616	CC3D220JAHGEN	CERAMIC	22P J	2K
C617	CG2J123KAPAQN	MT-POLYEST		630V
C619	CE1V560MMVANN	ELECT	56U M	35V
C619	CE1V560MNRANN	ELECT	56U M	35V
C620	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C621	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C624	CK1H473KLZBNG	CERAMIC	0.047U K	50V
C625	CK1H104KLZBNG	CERAMIC	0.0470 K	50V
C626	CE1H100MMVANN	ELECT	10U M	50V
C626	CE1H100MNRANN	ELECT	100 M	50V
C627	CK1H105KGNBNG	CERAMIC	100 W	50V
	CC1H681JLZCNG	CERAMIC	680P J	50V
C628				
C629	CC1H101JLZCNG	CERAMIC	100P J	50V
C630	CM2J823JAWAQN	MT-POLYPRO		630V
C631	CK3D101KANHAN	CERAMIC	100P K	2K
C631	CK3D101KCRDAN	CERAMIC	100P K	2K
C632	CK3D471KANHAN	CERAMIC	470P K	2K
C632	CK3D471KCRDAN	CERAMIC	470P K	2K
C633	CK3D150JTDANG	CERAMIC	15P J	2K
C634	CK3D150JTDANG	CERAMIC	15P J	2K
C635	CK1E474KLZBNG	CERAMIC	0.47U K	25V
C637	CKXAV2E222AAC	CERAMIC	2200P M	250V
C639	CK1H102KLZBNG	CERAMIC	1000P K	50V
C640	CE1H220MMVANN	ELECT	22U M	50V
C640	CE1H220MNRANN	ELECT	22U M	50V
C642	CK1H104KLZBNG	CERAMIC	0.1U K	50V
C643	CK1H102KLZBNG	CERAMIC	1000P K	50V
C644	CKXAV2E471AAC	CERAMIC	470P M	250V
C645	CKXAV2E101AAC	CERAMIC	100P M	250V
C703	CE1V471M2FANN	ELECT	470U M	35V
C703	CE1V471M6QANN	ELECT	470U M	35V
C704	CE1V471M2FANN	ELECT	470U M	35V
C704	CE1V471M6QANN	ELECT	470U M	35V
C705	CE1V471M2FANN	ELECT	470U M	35V
C705	CE1V471M6QANN	ELECT	470U M	35V
C708	CE1E102M2FANN	ELECT	1000U M	25V
C708	CE1E102M6QANN	ELECT	1000U M	25V
C709	CE1E102M2FANN	ELECT	1000U M	25V
C709	CE1E102M6QANN	ELECT	1000U M	25V

Schematic Location	Part No.	Des	scription		Schematic Location	Part No.	Description
C710	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D614	DDXLBB053—-G	DIODE 1SS35
C711	CK1E475KGNBNG	CERAMIC	4.7U K	25V	D616	DDEU1N	DIODE EU1
C712	CK3A102KANHAN	CERAMIC	1000P K	1K	D616	DDXLBB017—-N	DIODE EU1
C712	CK3A102KCRDAN	CERAMIC	1000P K	1K	D617	DD1SS352G	DIODE 1SS352-(TPH3)
C713	CE1C272M2FANN	ELECT	2700U M	16V	D617	DD1SS355G	DIODE 1SS355-TE-17
C713	CE1C272M6QANN	ELECT	2700U M	16V	D617	DDXLBB053—-G	DIODE 1SS35
C714	CE1C102M6RANN	ELECT	1000U M	16V	D618	DD1SS352G	DIODE 1SS352-(TPH3)
C714	CE1C102MMYANN	ELECT	1000U M	16V	D618	DD1SS355G	DIODE 1SS355-TE-17
C715	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D618	DDXLBB053—-G	DIODE 1SS35
C717	CE1H220MMVANN	ELECT	22U M	50V	D619	DD1SS352G	DIODE 1SS352-(TPH3)
C717	CE1H220MNRANN	ELECT	22U M	50V	D619	DD1SS355G	DIODE 1SS355-TE-17
C718	CK1H105KGNBNG	CERAMIC	1U K	50V	D619	DDXLBB053—-G	DIODE 1SS35
C719	CK1H105KGNBNG	CERAMIC	1U K	50V	D620	DZ02DZ18Y—-G	ZENER DIODE 02DZ3.9Y(TPH3)
C720	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D620	DZUDZS18B—-G	ZENER DIODE UDZS18B-TE-17
C721	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D620	DZXLBXB18B—G	ZENER DIODE MM3Z 18B
C722	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D621	DD1SS352G	DIODE 1SS352-(TPH3)
C723	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D621	DD1SS355G	DIODE 1SS355-TE-17
C724	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D621	DDXLBB053—-G	DIODE 1SS35
C725	CK1H102KLZBNG	CERAMIC	1000P K	50V	D622	DD1SS352G	DIODE 1SS352-(TPH3)
C726	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D622	DD1SS355G	DIODE 1SS355-TE-17
C727	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D622	DDXLBB053—-G	DIODE 1SS35
C729	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D623	DZMTZJ27B—-N	ZENER DIODE MTZJ27B
C730	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D624	DD1SS352G	DIODE 1SS352-(TPH3)
C732	CK1E474KLZBNG	CERAMIC	0.47U K	25V	D624	DD1SS355G	DIODE 1SS355-TE-17
C733	CK1H104KLZBNG	CERAMIC	0.1U K	50V	D624	DDXLBB053—-G	DIODE 1SS35
					D625	DD1SS352G	DIODE 1SS352-(TPH3)
	DIODES				D625	DD1SS355G	DIODE 1SS355-TE-17
D604		DIODE D10V	/DCO 7101		D625	DDXLBB053—-G	DIODE 1SS35
D601 D602	DDXLBB091—-N DDEG01C——-N	DIODE D10X			D626	DD1SS352G	DIODE 1SS352-(TPH3)
D602	DDZLBB011—-N	DIODE EGOT			D626	DD1SS355G	DIODE 1SS355-TE-17
D603	DDEU1N	DIODE EU1	U		D626	DDXLBB053—-G	DIODE 1SS35
D603	DDXLBB017—-N	DIODE EU1			D627	DZXLBZA13B—N	ZENER DIODE MTZJ13B
D605	DCBPC-817MC-N		PLE BPC-817	7MC	D628	DDXLBB088—-N	DIODE STPS20LCD100C
D605	DCPC123X5YFZN		PLE PC123X		D628	DDXLBB090—-N DDSBT80-06JSN	DIODE SBR200-10JS
D606	DCBPC-817MC-N		PLE BPC-817		D629		DIODE SBT80-06JS
D606	DCPC123X5YFZN		PLE PC123X		D629 D630	DDXLBB086—-N	DIODE STPS10LCD60C DIODE SBT80-06JS
D607	DCBPC-817MC-N		PLE BPC-817		D630	DDSBT80-06JSN DDXLBB086—-N	DIODE STPS10LCD60C
D607	DCPC123X5YFZN		PLE PC123X		D630 D631	DZ02DZ18Y—-G	ZENER DIODE 02DZ3.9Y(TPH3)
D608	DCBPC-817MC-N		PLE BPC-817		D631	DZUDZS18B—-G	ZENER DIODE UDZS18B-TE-17
D608	DCPC123X5YFZN		PLE PC123X		D631	DZXLBXB18B—G	ZENER DIODE MM3Z 18B
D609	DD1SS352G	DIODE 1SS3			D632	DZ02DZ18Y—-G	ZENER DIODE 02DZ3.9Y(TPH3
D609	DD1SS355G	DIODE 1SS3			D632	DZUDZS18B—-G	ZENER DIODE UDZS18B-TE-17
D609	DDXLBB053—-G	DIODE 1SS3	35		D632	DZXLBXB18B—G	ZENER DIODE MM3Z 18B
D610	DZ02DZ18Y—-G	ZENER DIOE	E 02DZ3.9Y(	TPH3)	D633	DZ02DZ6.2Y—G	ZENER DIODE 02DZ6.2Y(TPH3)
D610	DZUDZS18BG		E UDZS18B-		D633	DZUDZS6.2B—G	ZD UDZS-TE-176.2B
D610	DZXLBXB18B—G	ZENER DIOE	E MM3Z 18E	}	D633	DZXLBXB6.2B-G	ZENER DIODE MM3Z6V2B
D611	DDAG01AN	DIODE AG01	Α		D636	DD1SS352G	DIODE 1SS352-(TPH3)
D612	DD1SS352G	DIODE 1SS3	352-(TPH3)		D636	DD1SS355G	DIODE 1SS355-TE-17
D612	DD1SS355G	DIODE 1SS3	55-TE-17		D636	DDXLBB053—-G	DIODE 1SS35
D612	DDXLBB053—-G	DIODE 1SS3	35		D637	DD1SS352G	DIODE 1SS352-(TPH3)
D613	DD1SS352G	DIODE 1SS3	52-(TPH3)		D637	DD1SS355G	DIODE 1SS355-TE-17
D613	DD1SS355G	DIODE 1SS3	355-TE-17		D637	DDXLBB053—-G	DIODE 1SS35
D613	DDXLBB053—-G	DIODE 1SS3	35		D640	DZ02DZ18Y—-G	ZENER DIODE 02DZ3.9Y(TPH3)
D614	DD1SS352G	DIODE 1SS3			D640	DZUDZS18B—-G	ZENER DIODE UDZS18B-TE-17
D614	DD1SS355G	DIODE 1SS3	355-TE-17		D640	DZXLBXB18B—G	ZENER DIODE MM3Z 18B


Schematic Location	Part No.	Description	Schematic Location	Part No.	Des	scription
	INTEGRATEI	D CIRCUITS	R609	RGF5602FTCANL	MT-GLAZE	56K FA 1/10W
IC601	QSTR-A6051M-N	IC STR-A6051M	R610	RGF1203JTCANL	MT-GLAZE	120K JA 1/10W
IC602	QSSC9512SP	IC SSC9512S	R611	RS1R680JGCAEN	OXIDE-MT	0.68 JA 1W
IC603	QXXAVC950—-P	IC LM393D	R612	RGB15R0JTBANL	MT-GLAZE	15 JA 1/4W
IC604	QTL431ATA—-N	IC TL431ATA	R613	RSXLB2334JXAS	OXIDE-MT	330KJA 2W
IC605	QTL431ATA—-N	IC TL431ATA	R614	RGB56R0JTBANL	MT-GLAZE	56 JA 1/4W
			R615	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
			R616	RGF5601JTCANL	MT-GLAZE	5.6K JA 1/10W
	COILS		R617	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
L601	1LB4F35B0350N	LINE FILTER	R618	RGF1004FTCANL	MT-GLAZE	1M FA 1/10W
L601	1LB4F35B0430N	LINE FILTER	R619	RGF1004FTCANL	MT-GLAZE	1M FA 1/10W
L602	1LB4F35B0380N	LINE FILTER	R620	RGF3902FTCANL	MT-GLAZE	39K FA 1/10W
L602	1LB4F35B0440N	LINE FILTER	R621	RGF5601FTCANL	MT-GLAZE	5.6K FA 1/10W
L605	1LB4L26B1510N	"INDUCTOR ,3UH"	R622	RGF3902FTCANL	MT-GLAZE	39K FA 1/10W
L605	1LB4L26B1550N	"INDUCTOR ,3UH"	R623	RGB1004JTBANL	MT-GLAZE	1M JA 1/4W
L606	1LB4L26B1510N	"INDUCTOR ,3UH"	R624	RGB1004JTBANL	MT-GLAZE	1M JA 1/4W
L606	1LB4L26B1550N	"INDUCTOR ,3UH"	R625	RGB1004JTBANL	MT-GLAZE	1M JA 1/4W
L607	1LB4L26B1470N	"INDUCTOR,1.0UH"	R626	RGF2203JTCANL	MT-GLAZE	220K JA 1/10W
L607	1LB4L26B1560N	"INDUCTOR,1.0UH"	R627	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
			R628	RS2R150JGDAGN	OXIDE-MT	0.15 JA 2W
			R629	RGB1004JTBANL	MT-GLAZE	1M JA 1/4W
	TRANSISTO	RS	R630	RGB1004JTBANL	MT-GLAZE	1M JA 1/4W
Q601	TFQPF16N25C-N	TR FQPF16N25C	R631	RGF3302FTCANL	MT-GLAZE	33K FA 1/10W
Q602	TFQPF16N25C-N	TR FQPF16N25C	R634	RGF4700JTCANL	MT-GLAZE	470 JA 1/10W
Q603	T50A02CH-E—P	TR 50A02CH-TL-E	R635	RGF2700FTCANL	MT-GLAZE	270 FA 1/10W
Q604	T2SC3928A1R-P	TR 2SC3928A1R	R636	RGB22R0JTBANL	MT-GLAZE	22 JA 1/4W
Q604	T2SC3928A1S-P	TR 2SC3928A1S	R637	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
Q604	TXXLBB006—-P	TR MMBTSC3928R	R638	RGB15R0JTBANL	MT-GLAZE	15 JA 1/4W
Q605	TXXLBB014—-P	TR 2N7002	R639	RGB10R0JTBANL	MT-GLAZE	10 JA 1/4W
Q606	T2SC3928A1R-P	TR 2SC3928A1R	R640	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
Q606	T2SC3928A1S-P	TR 2SC3928A1S	R641	RGB15R0JTBANL	MT-GLAZE	15 JA 1/4W
Q606	TXXLBB006—-P	TR MMBTSC3928R	R642	RGB10R0JTBANL	MT-GLAZE	10 JA 1/4W
Q607	T2SC3928A1R-P	TR 2SC3928A1R	R644	RGF4702JTCANL	MT-GLAZE	47K JA 1/10W
Q607	T2SC3928A1S-P	TR 2SC3928A1S	R646	RGF5600JTCANL	MT-GLAZE	560 JA 1/10W
Q607	TXXLBB006—-P	TR MMBTSC3928R	R648	RXXAVA105JABN	RESISTER	1.0M JA 1/2W
Q608	T2SC3928A1R-P	TR 2SC3928A1R	R649	RGF3002JTCANL	MT-GLAZE	30K JA 1/10W
Q608	T2SC3928A1S-P	TR 2SC3928A1S	R660	RGB1802JTBANL	MT-GLAZE	18K JA 1/4W
Q608	TXXLBB006—-P	TR MMBTSC3928R	R661	RGB33R0JTBANL	MT-GLAZE	33 JA 1/4W
Q609	TISA1235AC1EP	TR ISA1235AC1E	R662	RGB33R0JTBANL	MT-GLAZE	33 JA 1/4W
Q609	TISA1235AC1FP	TR ISA1235AC1F	R663	RGB10R0JTBANL	MT-GLAZE	10 JA 1/4W
Q609	TXXLBB005—-P	TR MMBTSA1235F	R700	RGF2200FTCANL	MT-GLAZE	220 FA 1/10W
Q610	T2SC3928A1R-P	TR 2SC3928A1R	R702	RGF8201FTCANL	MT-GLAZE	8.2K FA 1/10W
Q610	T2SC3928A1S-P	TR 2SC3928A1S	R703	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
Q610	TXXLBB006—-P	TR MMBTSC3928R	R705	RGB1002JTBANL	MT-GLAZE	10K JA 1/4W
Q611	TISA1235AC1EP	TR ISA1235AC1E	R706	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
Q611	TISA1235AC1FP	TR ISA1235AC1F	R707	RGF1002FTCANL	MT-GLAZE	10K FA 1/10W
Q611	TXXLBB005—-P	TR MMBTSA1235F	R708	RGF5601FTCANL	MT-GLAZE	5.6K FA 1/10W
			R709	RGF6800FTCANL	MT-GLAZE	680 FA 1/10W
	DEGICTORS		R710	RGF1001FTCANL	MT-GLAZE	1K FA 1/10W
_	RESISTORS		R711	RGB4700JTBANL	MT-GLAZE	470 JA 1/4W
R601	DHXAVB034—-N	THERMISTOR NTPAD5R1LDUB0	R713	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R603	RXXAVA685JABN	RESISTER 6.8M JA 1/2W	R714	RGF1002FTCANL	MT-GLAZE	10K FA 1/10W
R605	RGF10R0JTCANL	MT-GLAZE 10 JA 1/10W	R715	RGF3900FTCANL	MT-GLAZE	390 FA 1/10W
R606	RS11R00JGCAEN	OXIDE-MT 1 JA 1W	R716	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R607	RGB1004JTBANL	MT-GLAZE 1M JA 1/4W	R717	RGF1002FTCANL	MT-GLAZE	10K FA 1/10W
R608	RGB1004JTBANL	MT-GLAZE 1M JA 1/4W	R718	RGF1002FTCANL	MT-GLAZE	10K FA 1/10W
			10	IOOLI IOINE		10111111111000


Schematic	Part No.	Des	cription
Location			
R719	RGF3301JTCANL	MT-GLAZE	3.3K JA 1/10W
R720	RGF3301JTCANL	MT-GLAZE	3.3K JA 1/10W
R721	RGF1501JTCANL	MT-GLAZE	1.5K JA 1/10W
R722	RGF3002JTCANL	MT-GLAZE	30K JA 1/10W
R723	RGF1203JTCANL	MT-GLAZE	120K JA 1/10W
R724	RGF4702JTCANL	MT-GLAZE	47K JA 1/10W
R725	RGF3901FTCANL	MT-GLAZE	3.9K FA 1/10W
R726	RGF3301JTCANL	MT-GLAZE	3.3K JA 1/10W
R727	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
R728	RGF1201JTCANL	MT-GLAZE	1.2K JA 1/10W
R729	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R730	RGF1002FTCANL	MT-GLAZE	10K FA 1/10W
R731	RGF4700JTCANL	MT-GLAZE	470 JA 1/10W
R732	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R733	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R734	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R735	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R736	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R737	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R738	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R739	RGF4701JTCANL	MT-GLAZE	4.7K JA 1/10W
R740	RGF2202JTCANL	MT-GLAZE	22K JA 1/10W
R741	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R742	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R743	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R744	RGF1002JTCANL	MT-GLAZE	10K JA 1/10W
R745	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R746	RGF1001JTCANL	MT-GLAZE	1K JA 1/10W
R747	RGF2201JTCANL	MT-GLAZE	2.2K JA 1/10W
R749	RN1R010FTDANL	MT-FILM	0.01 FA 1W
R750	RN1R010FTDANL	MT-FILM	0.01 FA 1W
R762	RGF3302FTCANL	MT-GLAZE	33K FA 1/10W
R765	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R766	RGF1003JTCANL	MT-GLAZE	100K JA 1/10W
R767	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R768	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R769	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R770	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R771	RGB4701JTBANL	MT-GLAZE	4.7K JA 1/4W
R772	RGB6801JTBANL	MT-GLAZE	6.8K JA 1/4W
R773	RGB6801JTBANL	MT-GLAZE	6.8K JA 1/4W
R774	RGB6801JTBANL	MT-GLAZE	6.8K JA 1/4W
R775	RGB6801JTBANL	MT-GLAZE	6.8K JA 1/4W
R776	RGB6801JTBANL	MT-GLAZE	6.8K JA 1/4W

Schematic Location	Part No.	Description
	MISCELLAN	EOUS
A400	1AA0B10N29100	"ASSY,PWB,POWER N8LF"
F601	FFXLBB008CQ-J	FUSE 250V 4A
SC601	1AV4Z30B0270N	SURGE-ABSORBER
T601	1LB4L51B1820N	"TRANS,POWER,PULSE"
T602	1LB4L51B1830N	"TRANS,POWER,PULSE"
VA601	DVS14K385E2-N	VARISTOR S14K385E2
VA602	DVS14K385E2-N	VARISTOR S14K385E2


# COMPONENT AND TESTPOINT LOCATIONS

#### **MAIN BOARD PARTS SIDE**







## **CONTROL BOARD PART SIDE**




## **CONTROL BOARD SOLDER SIDE**




## PWB RC\_LED PART SIDE




# PWB RC\_LED SOLDER SIDE




## **POWER BOARD PART SIDE**




## **POWER BOARD SOLDER SIDE**



# **BLOCK DIAGRAM POWER LINES**




# **BLOCK DIAGRAM SIGNAL LINES**




# IC BLOCK DIAGRAMS

## IC001, Audio AMP




# **IC BLOCK DIAGRAMS (CONT.)**


# IC1670 Voltage Regulator




## **IC803 EEPROM**



## IC1680 DC to DC Regulator




## IC1600, DC to DC Converter




# **IC BLOCK DIAGRAMS (CONT.)**


### **IC5500 Video Processing**



## IC6270, Low output Amplifier




## IC6600, USB protection




# **IC BLOCK DIAGRAMS (CONT.)**

#### IC5700, DDR: Double Data Rate SDRAM




## TROUBLESHOOTING FLOW CHARTS

### **NO POWER**




## TROUBLESHOOTING FLOW CHARTS (continued)

### **NO AUDIO**



## TROUBLESHOOTING FLOW CHARTS (continued)

#### **NO VIDEO**



# **CONTROL PORT FUNCTIONS**

# System Control (TV SUB CPU IC 801)


PIN	IC specification	Assignment	10	Explanation
1	P12/SCK0	REG SW4	OUT	REG SW4 (ON : High OFF : Low)
2	P13/SO1	REG SW5	OUT	no use (REG SW5)
3	P14/SI1/SB1	IIC-BUS for NV	1/0	Data of IIC Bus Active 'L' for IIC data NV
4	P15/SCK1	IIC-BUS for NV	OUT	Clock of IIC Bus Active 'L' for IIC clock NV
5	P16/T1PWML	REG SW2	OUT	REG SW2 (ON : High OFF : Low)
6	P17/T1PWMH/BUZ	REG SW3	OUT	REG SW3 (ON: Low OFF: High)
7	PWM2	illumination	OUT	no use (illumination LED output)
8	PWM3	no use	IN	no use (PWR DET)
9	VDD2	Power IN	IN	VDD2 (5Vdc±10%)
10	VSS2	Vss	IN	GND (0Vdc)
11	P00	Category2	IN	Hard option for category
12	P01	Category1	IN	Hard option for category
13	P02		IN	Hard option for category
14	P03	Category0 Panel Size2	IN	Hard option for panel size
l	P04	Panel Size2		•
15	P05/CKO	Panel Size0	IN	Hard option for panel size
16	P05/CKO P06/T6O		IN	Hard option for panel size  LED Control output for Power indicater
17		LED CNTRL	OUT	
18	P07/T70	TV Relay out	OUT	POWER Relay control output ON : High OFF : Low
19	P20/UTX/INT4/T1IN	UART OUT	OUT	Output of UART(Digital Module microcomputer pc. confidence)
20	P21/URX/INT4/T1IN	UART IN	IN	Input of UART (Digital Module microcomputer piece confidence)
21	P22/INT4/T1IN	PC Standby LED	OUT	LED control of PC Standby: High, Normal: Low
22	P23/INT4/T1IN	Audio MUTE	OUT	Audio Mute MUTE ON : Low OFF : High
23	P24/INT5/T1IN	Power Fail-2 IN	IN	LVDS Power Fail input for LCD model /(no used at PDP model:
				Setting output mode)
24	P25/INT5/T1IN	AMP STBY	OUT	AMP Standby control Stanby:Low Power on:High
25	P26/INT5/T1IN	HS DET	IN	"Detect H-Sync (Detect : High , PC Input)
26	P27/INT5/T1IN	VS DET	IN	"Detect V-Sync (Detect : High , PC Input)
27	PB7	RESET TV	OUT	RESET_TV for DM Watch Dog Timer
28	PB6	Boot SEL1	OUT	no use (Starting DM S/W download-SEL1 for US1T model)
29	PB5	Boot SEL2	OUT	no use (Starting DM S/W download-SEL2 for US1T model)
30	PB4	M OUT MUTE	OUT	MUTE ON Low OFF High
31	PB3	LINE OFF DET	OUT	no use (Detect LINE OFF output)
32	PB2	Reserve	OUT	Reserve (Set Low level)
_33	PB1	Reserve	OUT	Reserve (Set Low level)
34	PB0	Solution	IN	High:42~ model Low:19~32 model
35	VSS3	Vss	IN	GND 0Vdc
_36	VDD3	Power IN	IN	VDD3 (5Vdc±10%)
37	PC7	DBGP2	IN	Terminal for De-Bug 3
38	PC6	DBGP1	I/O	Terminal for De-Bug 2
39	PC5	DBGP0	I/O	Terminal for De-Bug 1
40	PC4	CLK	OUT	Writing on bord (CLK)
41	PC3	DATA0	I/O	Writing on bord (DATA0)
42	PC2	ENA/DATA1	I/O	Writing on bord (ENA / DATA1)
43	PC1	Ack out	OUT	Ack output for factory mode
44	PC0	STATUS in	IN	Status input for factory mode
45	AN6	sensor in	IN	light sensor input
46	P85	Reserve	OUT	(OPEN) (Set Low level)
47	P84	Panel Alarm	IN	no use (Panel Alarm)
48	AN3	Power Fail-1 IN	IN	TV Power Error(3.6V less) / Others (3.6V over)
49	P70/INT0/T0LCP	LINE OFF	IN	Detect AC Voltage Reduction (Normal : High)
50	P71/INT1/T0HCP	CEC input	IN	no use (CEC input)
		I		

PIN	IC specification	Assignment	10	Explanation
51	P72/INT2/T0IN	CEC output	OUT	no use (CEC output)
52	P73/INT3/T0IN	Rcin	IN	Remote control signal input
53	RES	RESET in	IN	CPU Reset input RESET : Low (and for on-board write)
54	XT1	Xin	IN	32.678KHz X'tal input (for clock timer)
55	XT2	Xout	OUT	32.678KHz X'tal output (for clock timer)
56	VSS1	Vss	IN	GND (0Vdc)
57	CF1/AN12	Xti	IN	Main clock input (8MHz ceramic oscillator)
58	CF2/AN13	Xto	OUT	Main clock output (8MHz ceramic oscillator)
59	VDD1	Power IN	IN	VDD1 (5Vdc±10%)
60	AN0	Key in	IN	Panel switch input
61	AN1	Reserve	IN	no use GND
62	P82	PANEL READY	IN	no use (Panel Ready for PDP)
63	P10	VS-ON	OUT	no use (VS-ON for PDP)
64	P11	REG SW1	OUT	REG SW1 (ON : Low OFF : High)

# <Table A>

28pin(SEL1)	29pin(SEL2)	Operation
High	High	USB download
High	Low	Starting Bank1
Low	High	Starting Bank2
Low	Low	Normal

# **Zoran 772 Periphericals**



### **SCHEMATIC NOTES**

#### **NOTES ON SCHEMATIC DIAGRAMS**

- 1. All resistance values in ohms K=1,000 M=1,000,000.
- 2. Resistors specified with resistance value are "1/6DJ."
- 3. Resistors specified with type of resistor, tolerance and resistance value are "1/4."
- 4. Unless otherwise noted on schematic, all capacitor values less than 1 are expressed in  $\mu F$  (Micro Farad), and the values more than 1 are in pF.
- 5. All capacitors are 50 WV rating unless oterhwise noted.
- 6. Unless otherwise noted on schematic, voltage reading taken with VOM from point indicated to chassis ground. Voltage reading taken using color-bar signal VHF channel 5, all controls at normal. Line voltage at 120 volts. Some voltages may vary with signal strength.
- 7. Waveforms were taken with color-bar signal and controls set for normal picture. Waveforms marked with an \* may vary with signal strength.
- 8. The Symbol ( indicates a fusible resistor, which protects the circuit from possible short circuits.
- 9. Parts enclosed with are related with X-radiation.
- 10. Isolation border line. Cold Side Hot Side
- 11. Schematic part location numbers may not always match the schematic symbols.

The schematic symbols and part descriptions are correct and should be used.

The part descriptions will be listed under the location number in the parts list.



#### **ELECTROSTATICALLY SENSITIVE DEVICES**

Many solid-state devices (especially Integrated Circuits) are Electrostatically Sensitive, and, therefore, require special handling techniques as described under "Servicing Electrostatically Sensitive Devices," on page two in this service literature.


#### **SERVICE NOTES:**

- 1. When replacing parts on circuit boards, clamp the lead wires to terminals before soldering.
- 2. When replacing high wattage resistors on circuit board, keep the resistor body 10 mm (3/8) from circuit board.
- 3. Keep wires away from high voltage and high temperature components.


#### PRODUCT SAFETY NOTICE

THE COMPONENTS DESIGNATED BY A  $\triangle$  ON THIS SCHEMATIC DIAGRAM DESIGNATE COMPONENTS WHOSE VALUES ARE OF SPECIAL SIGNIFICANCE TO PRODUCT SAFETY. SHOULD ANY COMPONENT DESIGNATED BY A  $\triangle$  NEED TO BE REPLACED, USE ONLY THE PART DESIGNATED IN THE PARTS LIST. DO NOT DEVIATE FROM THE RESISTANCE, WATTAGE AND VOLTAGE RATINGS SHOWN.

# IC, DIODE, AND TRANSISTOR PIN LAYOUTS




# PC BOARD CONNECTIONS AND LOCATIONS




### CAPACITOR AND RESISTOR CODE CHART

#### **CAPACITOR** (Example)



#### RESISTOR (Example)



For parts or service contact

Sanyo Manufacturing Corporation P.O. Box 2000 3333 Sanyo Road Forrest City, Arkansas 72335-2000

April 2010 SMC

